



Figures and illustrations in this User Manual are provided for reference only and may differ from actual product appearance. Product design and specifications may be changed without notice.

IMPORTANT WARRANTY INFORMATION

REGARDING TELEVISION FORMAT VIEWING

See the warranty card for more information on warranty terms.

Wide screen format LED Displays (with 16:9 aspect ratios, the ratio of the screen width to height) are primarily designed to view wide screen format full-motion video. The images displayed on them should primarily be in the wide screen, 16:9 ratio format, or expanded to fill the screen, if your model offers this feature, with the images constantly in motion. Displaying stationary graphics and images on the screen, such as the dark sidebars on non-expanded standard format television video and programming, should be limited to no more than 5% of the total television viewing time per week. Additionally, viewing other stationary images and text such as stock market crawls, video game displays, station logos, web sites or computer graphics and patterns, should be limited as described above for all televisions.

Displaying stationary images that exceed the above guidelines can cause uneven aging of LED Displays that leave subtle, but permanent burned-in ghost images in the LED picture. To avoid this, the way the programming and images, and primarily display full screen moving images, not stationary patterns or dark bars. On LED models that offer picture sizing features, use these controls to view different formats as a full screen picture.

Be careful about the television formats you select and the length of time you view them. Uneven LED aging as a result of format selection and use, as well as burning in images, are not covered by your Samsung limited warranty.

• SAMSUNG ELECTRONICS NORTH AMERICAN LIMITED WARRANTY STATEMENT

Subject to the requirements, conditions, exclusions and limitations of the original Limited Warranty supplied with Samsung Electronics (SAMSUNG) products, and the requirements, conditions, exclusions and limitations contained herein, SAMSUNG will additionally provide Warranty Repair Service in the United States on SAMSUNG products purchased in Canada, and in Canada on SAMSUNG products purchased in the United States, for the warranty period originally specified, and to the Original Purchaser only.

The above described warranty repairs must be performed by a SAMSUNG Authorized Service Center. Along with this Statement, the Original Limited Warranty Statement and a dated Bill of Sale as Proof of Purchase must be presented to the Service Center.



© 2015 Samsung Electronics Co., Ltd. All rights reserved.

The On Screen Menus

Your TV has two kinds of menus, the Main menu and the various Tools menus. The Main menu gives you access to most or all of the menu options available on your TV. The Tools menus display a selected number of frequently used menu options that change depending on the screen you are viewing. A Tools menu symbol () in the lower right side of the screen indicates that a Tools menu is available.

The Main menu has seven primary categories:

- Picture
- Sound
- Channel
- Setup
- Input
- Application
- Support

To view the Main menu, press the MENU button on your remote. To view a Tools menu, press the TOOLS button on your remote.

The menu options that appear in the Main menu depend on the Source you have selected. For example, if you have selected the HDMI source, the Channel category will not appear. To see the Channel category, you must first select TV in the Source List.

The Menu options are presented below, arranged by Main menu categories. A Tools button symbol () next to an option name indicates the option is also available in one of the Tools menus.

Picture Menu

Mode

Select your preferred picture mode.

When your TV is connected to a PC, you can only select **Entertain** and **Standard**.

- Dynamic:** Brightens the screen. Suitable for a bright room.
- Standard:** Suitable for a normal.
- Movie:** Darkens the screen, making it less glary. Suitable for watching movies in a darkened room.
- Entertain:** Sharpens the picture. Suitable for games.
- Only available when the TV is connected to a PC.

Backlight / Contrast / Brightness / Sharpness / Color / Tint (G/R)

- Backlight:** Adjusts the brightness of the screen by adjusting the brightness of the individual pixels.
- Contrast:** Increases or decreases the contrast between dark and light areas of the picture.
- Brightness:** Adjusts the brightness of the screen. Not as effective as Backlight.
- Sharpness:** Sharpens or dulls the edges of objects.
- Color:** Adjusts the color saturation. The higher the Color setting, the more intense the color. Low settings remove color and the picture becomes black, white and gray.
- Tint (G/R):** Adjusts the amount of green and red in the picture. As you increase the amount of green, the amount of red decreases and vice versa.
- When the TV is connected to a PC, you can only make changes to **Backlight**, **Contrast**, **Brightness**, and **Sharpness**.

Picture Options

When the TV is connected to a PC, you can only make changes to the **Color**, **Size** and **HDMI Black Level**.

- Color** **Zone** (**Cool / Standard / Warm**): Cool makes the picture bluer (cooler). Warm makes the picture redder (warmer).
- Warm** is deactivated when the picture mode is set to **Dynamic**.
- Size:** Set the size and aspect ratio of the picture on the screen. Your cable box or satellite receiver may have its own set of screen sizes as well. However, we highly recommend you use the TV's 16:9 mode most of the time.
- 16:9:** Sets the picture to the 16:9 wide screen format.
- Zoom1:** Provides moderate magnification of the picture. Sides, top, and bottom are cut off.
- Zoom2:** Provides larger magnification of the picture. Sides, top, and bottom are cut off.
- Wide Fit:** Enlarges the aspect ratio of the picture so the picture fits the entire screen.
- 4:3:** Sets the picture to the old 4:3 format and puts black or gray borders on the right and left of the picture.
- Do not watch your TV in the 4:3 format for a long time. Traces of borders displayed on the left, right and center of the screen may cause image retention (screen burn) which is not covered by the warranty.
- Screen Fit:** Displays the full image without any cut-off when your TV is inputting HDMI (720p / 1080i / 1080p) or Component (1080i / 1080p) HD signals.
- HD (High Definition) has a 16:9 aspect ratio and 1080i/1080p (1920x1080) or 720p (1280x720) resolution.
- You can adjust and store settings for each external device you have connected to an input on the TV. Picture Sizes available by Input Source are listed below:

Custom: Magnifies or shrinks 16:9 pictures vertically and/or horizontally. A magnified or shrunk picture can be moved left, right, up, and down.

Input Source	Picture Size
ATV, AV, Component (480i, 480p)	16:9, Zoom1, Zoom2, 4:3
DTV (1080i, 1080p), Component (1080i, 1080p), HDMI (720p, 1080i, 1080p)	16:9, Wide Fit, 4:3, Screen Fit

- Digital Clean View (Off / Low / Medium / High / Auto):** If the broadcast signal received by your TV is weak, you can activate the **Digital Clean View** feature to reduce any static and ghosting that may appear on the screen.
- When the signal is weak, try all the Digital Clean View options until the TV displays the best picture.

- HDMI Black Level (Normal / Low):** For HDMI signals, select the black level to adjust the screen depth. Low make blacks look darker.
- Available only in HDMI mode (RGB signals).

- Film Mode (Off / Auto1 / Auto2):** Sets the TV to automatically sense and process film signals from all sources and adjusts the picture for optimum quality.
- Available in ATV, DTV (Interface), AV, COMPONENT (480i / 1080i) and HDMI (480i / 1080p).

- Motion Lighting (Off / On):** When on, the TV automatically adjusts the brightness of the screen in response to the brightness of the room. In bright light, the screen brightens. In dim light, the screen dims.

Picture Reset

- Picture Reset (Reset Picture Mode/Cancel):** Resets the picture settings to their factory defaults.

If you selected Manual:

The **Clock Set** screen appears. Use the **▲/▼** buttons to change the values in each field or use the number buttons to enter the values directly. Use the **◀/▶** buttons to move from field to field. When done with all the fields, press ENTER .

Available only when **Clock Mode** is set to **Manual**.

- Sleep Timer **: Automatically shuts off the TV after a preset period of time. (30, 60, 90, 120, 150 and 180 minutes).
- To cancel the **Sleep Timer**, select **Off**.

Timer 1 / Timer 2 / Timer 3

Turns the TV on and off automatically at times and days you select. You can set three different on/off timer settings.

You must set the clock first.

- On Time / Off Time:** Set the hour, minute, am/pm, and Activate/Inactivate fields for the **On time** and **Off Time**. Use the **▶/◀** buttons to move from field to field. Use the **▲/▼** buttons to change the values in each field. To activate the timer with the setting you have chosen, set the Activate/Inactivate field to **Activate**.
- Volume:** Set the desired loudness.

- Contents:** To select what will be turned on when the timer setting is activated. You can set the TV to turn on a specific channel or play back contents such as photo or audio files. Use the **◀/▶** buttons to move to move to the Contents field, and then press the ENTER  button. The Contents screen appears. Use the **◀/▶** buttons to move from field to field. Use the **▲/▼** buttons to change the values in each field.

- **TV/USB:** Select **TV** or **USB**. The USB device must be connected to your TV before you can select USB.
- **Antenna:** Displays the current antenna source, **Air** or **Cable**.
- **Channel:** If you have selected TV, select the desired channel.
- **Music/Photo:** If you have selected USB, follow these steps to select a folder containing MP3 (Music) or JPEG (Photo) files on the USB device:

Choose between **English**, **Español**, and **Français**.

Setting the Time

- The time you set will appear when you press the INFO button.
- Clock:** Set the clock so you can use the various timer features of the TV.
- If you disconnect the power cord, you have to set the clock again.
- To set the clock, follow these steps:

- Select **Setup >Time > Clock**.
- Press ENTER  and select **Auto** or **Manual**, and then press ENTER  again.

If you selected Auto:

The TV will automatically download the correct time from a digital channel.

- Select **Time Zone**, and then press the ENTER  button. Use the **▲/▼** buttons to select your **Time Zone**, and then press ENTER .
- Select DST (Daylight Savings Time), and then press ENTER . Select **On** if you want to turn the DST adjustment on and off manually. Select **Off** to turn off the DST adjustment. Select **Auto** if you want the TV to adjust to DST automatically. Press ENTER  when done.
- DST and Time Zone** function are only available when the **Clock Mode** is set to **Auto**.

Sound Menu

Mode

- Standard:** Selects the normal sound mode.
- Music:** Emphasizes music over voices.
- Movie:** Provides the best sound for movies.
- Clear Voice:** Emphasizes voices over other sounds.

Equalizer

Available in Standard sound mode only.

- Balance L/R:** Adjusts the balance between the right and left speaker.
- 100Hz / 300Hz / 1KHz / 3KHz / 10KHz** (Bandwidth Adjustment): Adjusts the loudness of specific bandwidth frequencies.
- Reset:** Resets the equalizer to its default settings.

DTS TruSurround (On/Off)

Available in Standard sound mode only.

DTS TruSurround is a patented DTS technology that solves the problem of playing 5.1 multichannel content over two speakers. TruSurround delivers a compelling, virtual surround sound experience through any two-speaker playback system, including internal television speakers. It is fully compatible with all multichannel formats.

Preferred Language

Digital channels only.

Digital-TV broadcasts can transmit many audio tracks simultaneously (for example, simultaneous translations of a program into foreign languages).

You can only select a language from among the ones being broadcast.

Multi-Track Sound (MTS)

Analog channels only.

- Mono:** Select for channels that are broadcasting in mono or if you are having difficulty receiving a stereo signal.
- Stereo:** Select for channels that are broadcasting in stereo.
- SAP:** Select to listen to the Separate Audio Program, which is usually a foreign-language translation.
- Depending on the program being broadcast, you can listen to **Mono**, **Stereo** or **SAP**.

Auto Volume

Automatically adjusts the volume level when you change video sources or content so the level remains the same.

SPDIF Output

The SPDIF (Sony Philips Digital Interface) outputs an uncompressed digital audio signal when you connect the digital audio jack on the back of the TV to a digital audio in jack on a receiver or home theater.

- Audio Format:** You can select the Digital Audio output (SPDIF) format. The available Digital Audio output (SPDIF) format may differ depending on the input source.

- Audio Delay:** Lets you correct timing mismatches between the audio track and the video when you are watching the TV and listening to digital audio output from the TV through an external device such as an AV receiver. When you select **Audio Delay**, a slider appears. Use the left and right arrow buttons to adjust the slider. Press ENTER  when done (0ms ~ 250ms).

Other Features

Game Mode (On/Off)

When you connect a game console such as a PlayStation™ or Xbox™ to your TV, you can enjoy a more realistic gaming experience by turning on the **Game Mode** function.

- Precautions and limitations for game mode:
 - Before you disconnect the game console and connect another external device, set **Game Mode** to **Off** in the setup menu.
 - If you display the TV menu in **Game Mode**, the screen shakes slightly.
- Game Mode** is not available when the input source is set to **TV**.
- After connecting the game console, set **Game Mode** to **On**. You may notice slightly reduced picture quality.

Program Rating Lock

The **Program Rating Lock** feature lets you block programs you've determined are inappropriate for your children based on the program's ratings. To access the **Program Rating Lock** feature and make any changes, you must enter a PIN (personal identification number). To watch a blocked program, you must also enter the same PIN.

- Program Rating Lock** is not available in HDMI or **Component** mode.
- The default PIN number of a new TV set is "0-0-0-0-0". You can set your own PIN using the **Change PIN** function.

How It Works

When you access the **Program Rating Lock** Menu functions for the first time, the PIN input screen appears. Enter 0-0-0-0. The PIN screen closes and the **Program Rating Lock** Menu appears. Every time you access the **Program Rating Lock** functions, the PIN screen will appear and you must enter a PIN.

When the Rating Lock screen appears, select **Program Rating Lock**, and then press ENTER . Select **On**, and then press the ENTER  key again. Depending on what type of programs or movies you want to block, select one of the options on the screen, and then press the ENTER  button. The options are listed below:

- MPAA Rating:** You can block movies based on their MPAA ratings. The Motion Picture Association of America (MPAA) has implemented a rating system that provides parents or guardians with advanced information on which films are appropriate for children.
- Canadian English:** You can block TV programs based on their Anglophone Canadian ratings.
- Canadian French:** You can block TV programs based on their French Canadian ratings.
- Downloadable U.S. Rating:** Parental restriction information can be used while watching DTV channels.

Locking/Blocking Programs or Movies

You lock or block programs and/or movies in essentially the same way for each option. Each option displays a grid or table. All the tables have ratings listed on the left. The **TV Parental Guidelines** option also has kinds of content listed across the top: **ALL**: All TV ratings. / **FV**: Fantasy violence / **V**: Violence / **S**: Sexual situation / **L**: Adult Language / **D**: Sexually Suggestive Dialog.

When you finished making all your selections on the Timer screen, press either the ENTER  or RETURN button.

Speaker Select

If you are listening to the sound track of a broadcast or movie through an external receiver, you may hear a sound echo caused by the difference in decoding speed between the TV's speakers and the speakers attached to your audio receiver. If this occurs, set the TV to **External Speaker**.

- When you set **Speaker Select** to **External Speaker**, the TV's speakers are turned off. You will hear sound through the external speakers only. When you set **Speaker Select** to **TV Speaker**, both the TV's speakers and the external speakers are on. You will hear sound through both.

When **Speaker Select** is set to **External Speaker**, the **VOLUME** and **MUTE** buttons will not operate and the sound settings will be limited.

- If there is no video signal, both the TV's speakers and the external speakers will be mute.

Visual Impaired

(digital channels only)

Add verbal description to the main audio to help the visually impaired.

Dolby Digital Comp

Set Dolby Digital compression mode.

Sound Reset

- Reset All:** Resets all sound settings to the factory defaults.

Channel Menu

Memorizing Channels

When you first set up your TV using **Plug & Play**, the TV memorized the channels that were available over the air or through your cable system and added them to the **Channel List**. The **Antenna** and **Auto Program** functions described below let you re-run the channel memorization function without having to re-run the **Plug & Play** procedure.

Antenna (Air / Cable)

Before your television can memorize the available channels, you must select your TV's signal source, **Air** (using an antenna) or **Cable**. Select Menu **> Channel > Antenna > Air** or **Cable**. After you have selected the signal source, go on to the **Auto Program** function.

- Selecting the signal source using the **Antenna** function also determines the signal source the TV is tuned to. For example, if you receive your TV signal over the air, and you select **Cable**, you will see only snow. You must select **Air** to see a picture.

Auto Program

The **Auto Program** function memorizes all channels that are available over the air or through your cable system and adds them to the **Channel List**.

To start **Auto Program**, follow these steps:

- Push MENU  — **Channel** — **Auto Program** —> ENTER  on your remote. The Antenna Source screen appears.
- On the Antenna Source screen, select the source of your TV signal.

To lock/block movies or shows with certain ratings and/or kinds of content, click the square next to the rating and/or under the kind of content. A lock appears. To unlock/unblock, click the square again. When you click a lock rating, all the ratings above it will also display locks. You can also Allow All or Lock All. When done, press the RETURN button on your remote.

- Change PIN:** The Change PIN screen will appear. Choose any 4 digits for your PIN and enter them in **Enter New PIN** fields. Re-enter the same 4 digits in **Confirm New PIN** fields. When the Change PIN screen disappears, press the OK button. The TV has memorized your new PIN.
- If you forget the PIN, press the remote-control buttons in the following sequence, which resets the pin to "0-0-0-0-0": POWER (off) —> MUTE —> 8 —> 2 —> 4 —> POWER (on)

Caption

(On-Screen Text Dialogue)

- Caption:** You can switch the caption function on or off. If captions are not available, they will not be displayed on the screen.

- The **Caption** feature does not work in **Component** or **HDMI** mode.

- Caption Mode:** You can select the desired caption mode.

Default / CC1-CC4 / Text1-Text4: (analog channels only) The Analog Caption function operates in either analog TV channel mode or when a signal is supplied from an external device to the TV. (Depending on the broadcasting signal, the Analog Caption function may or may not work with digital channels.)

Default / Service1-Service6 / CC1-CC4 / Text1-Text4: (digital channels only) The Digital Captions function works with digital channels.

- Service1-6** may not be available in digital caption mode depending on the broadcast.

Digital Caption Options: (Digital channels only)
Size: Options include Default, Small, Standard and Large. The default is Standard.

Font Style: Options include Default and Styles 0 to 7. The default is Style 0.

Foreground Color: Options include Default, White, Black, Red, Green, Blue, Yellow, Magenta and Cyan. You can change the color of the letters. The default is White.

Background Color: Options include Default, White, Black, Red, Green, Blue, Yellow, Magenta and Cyan. You can change the background color of the captions. The default is Black.

Foreground Opacity: This adjusts the opacity of text. Options include Default, Transparent, Translucent, Solid and Flashing.

Background Opacity: This adjusts the opacity of the caption background. Options include Default, Transparent, Translucent, Solid and Flashing.

Return to Default: This option sets each Size, Font Style, Foreground Color, Background Color, Foreground Opacity and Background Opacity to its default.

- Digital Caption Options** are available only when you can select **Default** and **Service1 ~ Service6** in **Caption Mode**.

The Foreground and Background cannot be set to the same color.

Boot Logo

Enable/disable displaying the logo while the TV starts up.

Air

If your TV is connected to an antenna choose **Air**, and then press ENTER . The TV will automatically start memorizing channels.

Cable

If your TV is connected to a cable outlet, choose **Cable**, and then press ENTER . Go to Step 3.

Auto

If you choose **Auto**, and then press ENTER , the TV will automatically select the correct Antenna source. Go to Step 3.

- On the Cable Type screen, use the **◀/▶** / **▲/▼** buttons to select the type of digital and/or analog cable systems you have: **STD**, **HRC**, or **IRC**. Most systems are **STD (Standard)**. When done, select **Start**, and then press ENTER . The TV will start memorizing channels.

- Channel memorization can take up to 45 minutes, depending on your cable system.
- Memorized channels are added to the **Added Channels** list. These are the channels you will see when you use the Channel buttons on your remote.

Clear Scrambled Channel

This function filters out scrambled channels after **Auto Program** is completed. This process may take up to 20-30 minutes.

- Press the ENTER  button to stop the **Clear Scrambled Channel**.
- This function is only available in **Cable** mode.

Managing Channels

Channel List

See your list of Added channels, Favorite channels, or channels you've scheduled for viewing. Add or delete Favorite channels, add or delete channels from the Added Channels list, schedule channels or programs for viewing. Watch a channel by selecting the channel in the **All Channels**, **Added Channels**, or **Favorite** screen, pressing the **▲** / **▼** buttons, and then pressing the ENTER  button.

Selecting the signal source using the **Antenna** function also determines the signal source the TV is tuned to. For example, if you receive your TV signal over the air, and you select **Cable**, you will see only snow. You must select **Air** to see a picture.



Channel List Screens icons are listed on the left side. Select an icon using the ▲/▼ buttons to view each list.

- All Channels:** Shows all currently available channels including those you deleted from the **Added Channels** list.
- Added Channels:** Shows all **Added Channels**. These are the channels that appear when you press the CH button.
- Favorite:** Shows all favorite channels.
- Programmed:** Shows all channels and programs currently scheduled using **Timer Viewing**.

- Remote control buttons active on the **Channel**

- If the TV has no input during the time period set in **Auto Protection Time**, the Screen saver will run.
- The power-saving mode of some external hard disk drives may be released automatically when you connect them to the TV.
 - If you use a USB extension cable, the TV may not recognize the USB device or may not be able to read the files on the device.
 - If a USB device connected to the TV is not recognized, the list of files on the device is corrupted, or a file in the list is not played, connect the USB device to a PC, format the device, and check the connection.
 - If a file you deleted from the PC is still found when you run **Media Play**, use the "Empty the Recycle Bin" function on the PC to permanently delete the file.
 - **Photos** only supports the sequential jpeg format.
 - The **Videos** option does not support the scene search and thumbnail functions.
 - If the number of files and folders saved on a USB storage device is over approximately 4000, the files and folders may not appear and some folders may not open.
 - The maximum displayed number of files, including sub folders, in one folder of USB storage device is 2000.
 - The media may not be playing smoothly when using the device longer than USB 2.0.

Videos



1. In the **Media Play** menu, press the ◀ or ▶ button to select **Videos**, and then press the ENTER button.
2. Press the ◀▶/▲▼ buttons to select a video in the file list.
3. Press the ENTER button or (▶) (Play) button.
 - The file name is displayed on the top of the screen with the playing time.
 - If video time information is unknown, playing time and the progress bar are not displayed.
 - During video playback, you can search using the ◀ and ▶ buttons.

- ☞ In this mode, you can play movie clips contained in a game, but you cannot play the game itself.

Supported Subtitle Formats

- External

Name	File extension
MPEG-4 timed text	.txt
SAMI	.smi
SubRip	.srt
SubViewer	.sub
Micro DVD	.sub or .txt
SubStation Alpha	.ssa
Advanced SubStation Alpha	.ass

- Internal

Name	Container	Format
Xsub	AVI	Picture Format
SubStation Alpha	MKV	Text Format
Advanced SubStation Alpha	MKV	Text Format
SubRip	MKV	Text Format
MPEG-4 Timed text	MP4	Text Format

Supported Video Formats


File Extension	Container	Video Codec	Resolution	Frame rate(fps)	Bit rate (Mbps)	Audio Codec
		Motion JPEG	640x480		8	
*.avi *.mkv *.asf *.wmv *.mp4 *.3gp *.mov *.mpg *.mpeg *.ts *.tp *.mp *.mov *.flv *.vob *.avi *.divx	AVI MKV ASF MP4 MOV 3GP FLV VRO VOB PS TS	H.264 BP/MP+HP H.264 BP / MP / HP Divx 3.11 / 4 / 5 / 6 MPEG4 SP/ASP MCOV FLV Window Media Video (WMV) y8VC1 MPEG2 MPEG1				AC3 LPCM ADPCM (IMA, MS) AAC HE-AAC WMA Dolby MPEGMP3 DTS (Core, LBR) G.711A (Law, u-Law)
*.webm	WebM	VP8	1920x1080	6-30	20	Vorbis

Other Restrictions

- Codecs may not function properly if there is a problem with the content.
- Video content does not play or does not play correctly if there is an error in the content or container.
- Sound or video may not work if they have standard bit rates/ frame rates above the TV's compatibility ratings.
- If the Index Table has an error, the Seek (Jump) function will not work.
- When playing video over a network connection, the video may not play smoothly because of data transmission speeds.
- Some USB/digital camera devices may not be compatible with the TV.
- While the TV is playing a video at the bit rate of 10 Mbps or higher, the menu screens may be displayed slowly.

- Video Decoder**
- Supports up to H.264, Level 4.1
- H.264 FMO / ASO / RS, VC1 / AP L4 are not supported.
- GMC 2 or above is not supported.
- Audio Decoder**
- WMA 10 Pro supports up to 5.1 channels. Supports up to the M2 profile. WMA lossless audio is not supported.
- QCELP and AMR NB/WB are not supported.
- Vorbis is supported for up to 2 channels.
- Dolby Digital Plus is supported for up to 5.1 channels.
- The DTS LBR codec is only available for MKV / MP4 /TS containers.

Music



1. In the **Media Play** menu, press the ◀ or ▶ button to select **Music**, and then press the ENTER button.
2. Press the ◀▶/▲▼ buttons to select the desired Music in the file list.
 - ☞ During music playback, you can search using the ◀ and ▶ button.
3. Press the ENTER button or (▶) (Play) button.
 - ☞ (REW) (FF) buttons do not function during play.
 - ☞ Media Play only displays files with MP3 and PCM file extension. Other file extensions are not displayed, even if they are saved on the same USB device.
 - ☞ If the sound is abnormal when playing MP3 files, adjust the **Equalizer** in the **Sound** menu. (An over-modulated MP3 file may cause a sound problem.)

- Supported Photo Formats
- | Image | Photo | Resolution |
|-------|-------------|--------------|
| JPEG | Base-line | 15360 x 8704 |
| | Progressive | 1024 x 768 |
- Other Restrictions**
- CMYK, YCCO Color space JPEG are not supported.
- Playing Multiple Files**
- **Playing selected video/music/photo files**
 - 1. On the File List screen, highlight a file, and then press the Yellow button on your remote.
 - 2. Repeat Step 1 to select multiple files.
 - ☞ **NOTE**
 - A ◀ mark appears to the left of the selected files.
 - To cancel a selection, press the Yellow button again.
 - To deselect all selected files, press the TOOLS button, select **Deselect All**, and then the ENTER button.
 - 3. Press the TOOLS button, select **Play Selected Contents**, and then press the ENTER button.
 - **Playing a video/music/photo folder**
 - 1. With the folders on your USB device displayed, use the ◀▶/▲▼ buttons to highlight a folder.
 - 2. Press the TOOLS button, select **Play Folder**, and then press the ENTER button.

Photos



1. In the **Media Play** menu, press the ◀ or ▶ button to select **Photos**, then press the ENTER button.
2. Press the ◀▶/▲▼ buttons to select a photo in the file list.
3. Press the ENTER button or (▶) (Play) button.

- ☞ **NOTE**
 - While a photo list is displayed, press the (▶) (Play) / ENTER button on the remote control to start a slide show.
 - All files in the file list section will be displayed in the slide show.
 - During the slide show, files are displayed in order.
 - During the slide show, you can adjust the slide show speed using (◀) (REW) or (▶) (FF) button.
 - You can move to other files using ◀ or ▶ button.
- ☞ **Media Play** can play Music files automatically during a Slide Show if **Background Music** is set to **On**.
- ☞ You cannot change the **Mode** in **Background Music** until the Background Music file has finished loading.

Supported Photo Formats

Image	Photo	Resolution
JPEG	Base-line	15360 x 8704
	Progressive	1024 x 768

Other Restrictions

- CMYK, YCCO Color space JPEG are not supported.

Playing Multiple Files

■ Playing selected video/music/photo files

1. On the File List screen, highlight a file, and then press the Yellow button on your remote.
2. Repeat Step 1 to select multiple files.
 - ☞ **NOTE**
 - A ◀ mark appears to the left of the selected files.
 - To cancel a selection, press the Yellow button again.
 - To deselect all selected files, press the TOOLS button, select **Deselect All**, and then the ENTER button.
3. Press the TOOLS button, select **Play Selected Contents**, and then press the ENTER button.
- **Playing a video/music/photo folder**
1. With the folders on your USB device displayed, use the ◀▶/▲▼ buttons to highlight a folder.
2. Press the TOOLS button, select **Play Folder**, and then press the ENTER button.

Media Play - Additional Functions

■ Videos/Music/Photos Play Option menus

When playing a file, press the TOOLS button.

Category	Operation	Videos	Music	Photos
Title	You can select another video file to play directly.			
Repeat Mode	You can play movie and music files repeatedly.	✓	✓	
Picture Size	You can adjust the picture size to your preference.	✓		
Picture Mode	You can adjust the picture setting.	✓		✓
Sound Mode	You can adjust the sound setting.	✓	✓	✓
Subtitle Settings	You can play the video with Subtitles. This function only works if the subtitles have the same file name as the video.	✓		
Audio Format	You can select the digital audio output format.	✓		
Audio Language	You can change the audio language if the video has more than one language.	✓		
Stop Slide Show / Start Slide Show	You can start or stop a Slide Show.			✓
Slide Show Speed	You can select the slide show speed during the slide show.			✓
Background Music	You can set and select background music when watching a Slide Show.		✓	
Zoom	You can zoom into images in full screen mode.			✓
Rotate	You can rotate images in full screen mode.			✓
Information	You can see detailed information about the played file.	✓	✓	✓

Settings

Using the Setup Menu


- **DivX® Video On Demand:** Shows the registration code authorized for the TV. If you connect to the VOD web site and register with the 10-digit registration code, you can download the VOD activation file. Once you play it using Media Play, the registration is completed.
 - ☞ For more information on DivX® VOD, visit "http://vod.divx.com".
- **Information:** Select to view information about the connected USB device.

Other Information

Installing the Wall Mount Kit


The wall mount kit (sold separately) allows you to mount the TV on the wall.

For detailed information about installing the wall mount, see the instructions provided with the wall mount items. Contact a technician for assistance when installing the wall mount bracket. Samsung Electronics is not responsible for any damage to the product or injury to yourself or others if you elect to install the wall mount on your own.



Storage and Maintenance

- ☞ If a sticker was attached to the TV screen, some debris can remain after you remove the sticker. Please clean it before watching the TV.
- ☞ The exterior and screen of the product can get scratched during cleaning. Be sure to wipe the exterior and screen carefully using a soft cloth to prevent scratches.



License

- This DivX Certified® device has passed rigorous testing to ensure it plays DivX® video.
- To play purchased DivX movies, first register your device at vod.divx.com. Find your registration code in the DivX VOD section of your device setup menu.
- DivX Certified® to play DivX® video up to HD 1080p, including premium content.
- DivX®, DivX Certified® and associated logos are trademarks of DivX, LLC and are used under license. Covered by one or more of the following U.S. patents: 7,295,673; 7,460,668; 7,515,710; 7,519,274.
- This device supports DivX Plus Streaming® for enjoying HD movies and TV shows with advanced features (multi-language subtitles, multiple audio tracks, chapters, smooth FF/RW, etc.) streamed to your device.
- For DTS patents, see http://patents.dts.com. Manufactured under license from DTS Licensing Limited. DTS, the Symbol, & DTS and the Symbol together are registered trademarks, and DTS 2.0 Channel is a trademark of DTS, Inc. © DTS, Inc. All Rights Reserved.
- For DTS patents, see http://patents.dts.com. Manufactured under license from DTS Licensing Limited. DTS, the Symbol, & DTS in combination with the Symbol, and DTS Studio Sound are registered trademarks or trademarks of DTS, Inc. in the United States and/or other countries. © DTS, Inc. All Rights Reserved.
- Manufactured under license from Dolby Laboratories.
- Dolby and the double-D symbol are trademarks of Dolby Laboratories.
- HDMI**
- The terms HDMI and HDMI High-Definition Multimedia Interface, and the HDMI Logo are trademarks or registered trademarks of HDMI Licensing LLC in the United States and other countries.
- Open Source Announcement**
- To send inquiries and requests for questions regarding open sources, contact Samsung via Email (oss.request@samsung.com).

Wall Mount Kit Specifications (VESA)

- ☞ The wall mount kit is not supplied, but sold separately.
- Install your wall mount on a solid wall perpendicular to the floor.
- When attaching to other building materials, please contact your nearest dealer. If you install the TV on a ceiling or slanted wall, it may fall and result in severe personal injury.

NOTE

- Standard dimensions for wall mount kits are shown in the table below.
- When purchasing our wall mount kit, a detailed installation manual and all parts necessary for assembly are provided.
- Do not use screws that do not comply with the VESA standard screw specifications.
- Do not use screws that are longer than the standard dimension or do not comply with the VESA standard screw specifications. Screws that are too long may cause damage to the inside of the TV set.
- For wall mounts that do not comply with the VESA standard screw specifications, the length of the screws may differ depending on the wall mount specifications.
- Do not fasten the screws too firmly. This may damage the product or cause the product to fall, leading to personal injury. Samsung is not liable for these kinds of accidents.
- Samsung is not liable for product damage or personal injury when a non-VESA or non-specified wall mount is used or the consumer fails to follow the product installation instructions.
- Do not mount the TV at more than a 15 degree tilt.
- Always have two people mount the TV on a wall.

Product Family	TV size in inches	VESA screw hole specs (A * B) in millimeters	C (mm)	Standard Screw	Quantity
LED-TV	32	200 x 200	31.3 ~ 32.3	M8	4



Securing the TV to the Wall

- ☞ **Caution:** Pulling, pushing, or climbing onto the TV may cause the TV to fall. In particular, ensure that your children do not hang over or destabilize the TV; doing so may cause the TV to tip over, resulting in serious injuries or death. Follow all safety precautions provided on the included Safety Flyer. For added stability, install the anti-fall device for safety purposes, as follows.

To prevent the TV from falling

- ☞ Since the necessary brackets, screws, and string or cable are not supplied, please purchase these separately.
- 1. Insert the screws into the wall brackets and firmly fasten them to the wall. Make sure the screws are firmly fixed to the wall.
- ☞ We strongly recommend you drive the screws into a stud.
- 2. Using screws, insert the screws through the TV brackets, and then fasten the screws to the top VESA screw holes on the back of the TV.
- 3. Connect the brackets on the TV and the brackets on the wall with a strong string or cable, and then tie the string or cable tightly to the brackets.
- ☞ Verify all connections are properly secured. Periodically check the connections for any sign of fatigue or failure. If you have any doubt about the security of your connections, contact a professional installer.
- ☞ Install the TV close to the wall so that it does not fall.
- ☞ Connect the string or cable so that the brackets on the wall are at the same height or lower than the brackets on the TV. Untie the string or cable before moving the TV.
- ☞ To purchase a TV Holder kit, contact Samsung customer care.

Kensington Lock

The Kensington Lock is not supplied by Samsung. It is a device used to physically fix the system when using it in a public place. Refer to the manual provided with the Kensington Lock for additional information on proper use.

- ☞ Please find a (🔒) icon on the rear of the TV. The Kensington slot is beside the (🔒) icon.
- ☞ The position and color may differ depending on the model.

Mode	Resolution	Horizontal Frequency (kHz)	Vertical Frequency (Hz)	Pixel Clock Frequency (MHz)	Sync Polarity (H / V)	1366 x 768	1920 x 1080
IBM	640 x 350	31.469	70.086	25.175	+/-	✓	✓
	720 x 400	31.469	70.087	28.323	-/+	✓	✓
	640 x 480	35.000	66.667	30.240	-/+	✓	✓
	632 x 624	49.726	74.551	57.284	-/+	✓	✓
	1152 x 870	68.681	75.982	100.000	-/+	✓	✓
MAC	640 x 480	31.469	59.940	25.175	-/+	✓	✓
	640 x 480	37.861	72.809	31.500	-/+	✓	✓
	640 x 480	37.500	75.000	31.500	-/+	✓	✓
	800 x 600	37.879	69.317	45.000	+/-	✓	✓
	800 x 600	48.077	72.188	50.000	+/-	✓	✓
	800 x 600	48.875	75.000	49.500	+/-	✓	✓
	1024 x 768	46.383	60.054	69.000	-/+	✓	✓
	1024 x 768	56.476	70.069	75.000	-/+	✓	✓
	1024 x 768	60.023	75.029	78.750	+/-	✓	✓
VESA DMT	1152 x 864	67.500	75.000	108.000	+/-	✓	✓
	1280 x 720	45.000	60.000	74.250	+/-	✓	✓
	1280 x 800	49.702	69.810	83.500	+/-	✓	✓
	1280 x 1024	60.381	60.050	108.000	+/-	✓	✓
	1280 x 1024	79.976	75.023	135.000	+/-	✓	✓
	1366 x 768	47.712	59.790	85.500	+/-	✓	✓
	1440 x 900	55.335	59.897	102.500	-/+	✓	✓
	1600 x 900Pb	60.000	60.000	108.000	+/-	✓	✓
	1680 x 1050	65.290	59.954	146.250	+/-	✓	✓
	1920 x 1080	67.500	60.000	148.500	+/-	✓	✓

Troubleshooting

If the TV seems to have a problem, first review this list of possible problems and solution. If none of these troubleshooting tips apply, visit samsung.com, then click on Support, or call Samsung customer service at 1-800-SAMSUNG.

Problem	Possible Solution
Flickering and Dimming	If your Samsung Television is flickering or dimming sporadically, you may need to disable some of its energy efficient features like the Energy Saving feature. Follow the steps below with your remote to turn these features off or on. • Energy saving : MENU → Setup → Eco Solution → Energy Saving → Select Settings
Component Connections / Screen Color	If you find that the color on your Samsung television's screen is not correct or black and white, first run a Self Diagnosis. Test on the TV to make sure there are no device issues. • Self Diagnosis : User Menu → Support → Self Diagnosis → Picture Test • If the test is ok, try making sure you: • Your connections are all consistent. For example, if you've used the AV in jack on your TV, make sure you have used the AV Out jack on your video source. • Try making sure you have connected to the correct jacks. For example, if you use the Component jacks, labeled Pb, Pr, and Y, to connect your TV and video source, make sure you have connected the blue Pb jack on the video source to the blue Pb jack on the TV, the red Pr jack on the source to the red Pr jack on the TV.
Screen Brightness	If you find that the colors on your Samsung TV are correct but just a little too dark or bright, there are some settings you should check before calling for a repair. • Backlight, Contrast, Brightness, Sharpness, Color, Tint and so on. Go to "Picture" in the Menu, and then try adjusting these options.
Unwanted Powering off	If your Samsung TV appears to turn off by itself, there may be an issue with either your Timer settings or your Eco friendly No Signal Power Off feature. First make sure the Sleep Timer is not accidentally set. The Sleep Timer lets you fall asleep with the TV still on knowing that it will turn off after a certain period of time and not waste energy. • Sleep Timer : User Menu → Setup → Time → Sleep Timer - If the Sleep Timer is not activated, you may have engaged the No Signal Power Off or Auto Power Off feature. • No Signal Power Off : User Menu → Setup → Eco Solution → No Signal Power • Auto Power Off : User Menu → Setup → Eco Solution → Auto Power Off

Trouble Powering On	Before you turn the TV on, find the red light on the right or left bottom of your TV. Press the power on button on the TV or remote and the light should blink about 5 times before the TV turns on. If you find that you are having trouble powering on your Samsung television, there are a number of things to check it before making a call to the service department. • If you happen to be using the TV as a monitor and the stand-by light only blinks for a few seconds when you press the power button, your PC is in sleep mode. To take your PC out of sleep mode, press a key on your keyboard or move the mouse. Then try turning your TV on. If you're sure your power cord, remote control, and PC are functioning properly, you may be having a cable issue. If you have a cable or satellite box, your TV may appear to be off because the cable or satellite box is not outputting a signal. To test the signal output of your cable or satellite box, press the guide or info button on the cable or satellite box remote control. If the screen displays the guide or info data, the problem is caused by the box.
Stand Assembly	• If you have any trouble assembling the stand, refer to "Install the Stand" in the Start Up or Stand Installation Guide.
Cannot find a channel	• Re-run Plug & Play or run Auto Program. (go to MENU - Channel - Auto Program)
Poor Picture	First, perform the Picture Test and to see if your TV is displaying the test image properly. Go to MENU - Support - Self Diagnosis - Picture Test If the test image is properly displayed, the poor picture may be caused by the source or signal. • If you have an analog cable/satellite box, upgrade to a digital set top box. Use HDMI or Component cables to deliver HD (high definition) picture quality. • Cable/Satellite subscribers: Try HD channels from the channel line up. • Air/Cable Antenna connection: Try HD channels after running Auto Program. ☞ Many HD channels broadcast up scaled SD (Standard Definition) content. The picture quality of up scaled SD content is low. • Adjust the Cable/Set top box video output resolution to 1080i or 720p.
The picture is distorted: macroblock error, small block, dots, pixelization.	• Compression of video contents may cause picture distortion, especially on fast moving pictures such as those in sports and action movies. • A weak signal can cause picture distortion. This is not a TV problem. • Mobile phones used close to the TV (within 3.3ft) may cause noise in the picture on analog and digital channels.
Color is wrong or missing.	• If you're using a component connection, make sure the component cables are connected to the correct jacks. Incorrect or loose connections may cause color problems or a blank screen.
There is poor color or brightness.	• Adjust the Picture options in the TV menu. (go to Picture Mode / Color / Brightness / Sharpness) • Adjust the Energy Saving option in the TV menu. (go to MENU - Setup - Eco Solution - Energy Saving) • Try resetting the picture to the default picture settings. (go to MENU - Picture - Picture Reset)
The picture is black and white.	• If the picture size is set to Screen Fit, change it to 16:9. • Change the cable/satellite box resolution. • If you are using an AV composite input, connect the video cable (yellow) to the Green jack of Component Input 1 on the TV.
When changing channels, the picture freezes or is distorted or delayed.	• If connected to a cable box, please try to reset it. (Reconnect the AC cord and wait until the cable box reboots. It may take up to 20 minutes) • Set the output resolution of the cable box to 1080i or 720p.
Sound Problems	Perform the Sound Test to confirm that your TV audio is properly operating. (go to MENU - Support - Self Diagnosis - Sound Test) If the audio is OK, the sound problem may be caused by the source or signal. • Check the volume of the device (Cable/Sat Box, DVD, Blu-ray, etc.) connected to your TV.
There is no sound or the sound is too low at maximum volume.	• If you are using an external device, check the device's audio output option. Ex. you may need to change your cable box's audio option to HDMI if the box is connected to your TV using an HDMI cable. • Reboot the connected device by reconnecting the device's power cable.
The picture is good, but there is no sound.	• Check the cable connections. Make sure a video cable is not connected to an audio input. • For Antenna or Cable connections, check the signal information. A weak signal may cause sound distortion. • Perform the Sound Test as explained above.
No Picture, No Video	
The TV will not turn on.	• Make sure the AC power cord is securely plugged into the wall outlet and the TV. • Make sure the wall outlet is working. • Try pressing the POWER button on the TV to make sure the problem is not the remote. If the TV turns on, refer to "Remote control does not work" below.
The TV turns off automatically.	• Ensure the Sleep Timer is set to Off in the Time menu. • If your PC is connected to the TV, check your PC power settings. • Make sure the AC power cord is plugged securely into the wall outlet and the TV. • When you are watching TV connected to an antenna or cable connection, the TV will turn off after 10 - 15 minutes if there is no signal.

There is no picture/video.	• Check the cable connections. (Remove and reconnect all cables connected to the TV and external devices). • Set your external devices (Cable/Sat Box, DVD, Blu-ray etc) video outputs to match the connections to the TV input. For example, if an external device's output is HDMI, it should be connected to an HDMI input on the TV. • Make sure your connected devices are powered on. • Be sure to select the correct input source by pressing the SOURCE button on the remote control. • Reboot the connected device by reconnecting the device's power cable.
RF (Cable/Antenna) Connection	
The TV is not receiving all channels.	• Make sure the coaxial cable is connected securely. • Run Auto Program to add available channels to the channel list. • go to MENU - Channel - Auto Program then select Auto and make sure the correct Cable TV signal type is set in the menu. There are 3 options. (STD, HRC and IRC) • Verify the antenna is positioned correctly.
No Caption on digital channels.	• Check the Caption Setup menu. Try changing Caption Mode Service1 to CC1. • Some channels may not have caption data.
The picture is distorted: macroblock error, small block, dots, pixelization.	• Compression of video contents may cause picture distortion, especially on fast moving pictures such as those in sports and action movies. • A weak signal can cause picture distortion. This is not a TV problem.
Others	
Purple/green rolling horizontal bars and buzzing noise from the TV speakers with Component cable connection.	• Remove the left and right audio connections from the set-top-box. If the buzzing stops, this indicates that the set-top-box has a grounding issue. Replace the Component video cables with an HDMI connection.