

QRLB-T Universal



- a Kirk Universal L-Bracket
- b Kirk Quick Release Clamp
- c Stainless steel mounting screws
- d Allen wrench
- e Loctite

**Decide whether you will want the QR tightening knob facing the front or the back of the camera before beginning the installation process.*

STEP ONE



1. Apply **LOCTITE** on one of the **STAINLESS STEEL SCREW**

STEP TWO



2. Line up the **QUICK RELEASE** clamp on the **L-BRACKET** and insert screw. Finger-tighten the screw in the **QUICK RELEASE CLAMP**.

STEP THREE



3. Use the provided **ALLEN WRENCH** to tighten the screw just enough for it to hold.

STEP FOUR



4. Apply **LOCTITE** to the threads of the second screw and insert it through the bottom of the bracket. Finger-tighten the second screw

STEP FIVE



5. Use the provided **ALLEN WRENCH** to tighten both screws.

