Operation Manual mp-50v





mp-50v Monopod Package

Copyright © Eagle America Sales Corporation 2011

All rights reserved. Reproduction of any part of this document including images, artwork, or writing without prior written consent of Eagle America Sales Corporation in writing is strickly prohibited.

Safety



Where there is a risk of injury, or damage to equipment, this warning symbol will appear. This equipment may cause harm if not used in accordance with this operation manual.

Before operating this equipment, please read manual for safety.

- Always maintain payload to within the maximum capacity limit.
- Ensure plate lock lever is firmly tightend.
- Ensure unit is securely positioned, and all leg locks are in the locked position.
- Do not modify, or dismantle equipment, as it may cause damage, and injury.
- When using unit, ensure the lock knobs are fully loosened.
- Always remove camera and accessories before transporting.

Technical Specifications

Weight 0.7kg / 1.5lb

Height 59.5-170cm / 23.5"-67"

Payload 3kg / 6.6lb

Leg Section 4 Section

Camera Plate Quick Shoe Plate

Plate Attachment 1/4"-Screw with video pin

Contents

| Safety | 3 |
|--------------------------|---|
| Technical Specifications | |
| Components | |
| Operation | |
| Setting up the Monopod | 6 |
| Mounting the Camera | |
| Further Information | Q |



- 1 Video Pin
- 2 Quick Release Plate
- 3 QR Plate Lock Knob
- 4 Custom Foam Grip

- 5 Wrist Strap6 Aluminum Leg Section
- 7 Leg Lock
- 8 Rubber Foot

Setting up the monopod.

- 1. Remove monopod from carry case.
- 2. Extend monopod to desired height.
 - ① Unlock upper leg locks while holding the monopod.
 - ② Adjust legs to desired height, and re-engage leg locks. Repeat with lower leg locks if needed.
- 3. Mount camera.

1.



2.1



2.2



3.



Mounting the camera.




Load capacity is 3kg / 6.6lbs. - Do exceed the load capacity as it may cause damage to equipment or injury.

When mounting and removing camera, ensure the unit is firmly secured.

- 1. Remove the quick release plate.
 - ① Loosen the quick release plate lock lever.
 - 2 Pull quick release plate out.
- 2. Mount the camera to the quick release plate.

 Align the camera screw and video boss with the camera, and tighten camera screw securley.
- 3. Mount camera and quick release plate to the monood head.
 - ① With camera mounted, insert quick release plate back into the monopod head.
 - ② Tighten quick release plate lock lever securely, for final step.





Further Information

For more information on products listed in this manual, visit us online:

www.acebil.com

or contcact us at:

Eagle America Sales Corporation Acebil 1840 S Elena Suite 202 Redondo Beach, CA 90277

TEL: (310) 375-6600 FAX: (310) 375 6608

To view our full line of Acebil camera support equipment, visit us online:

www.acebil.com

