

# ELE-DCFLY

## HDSLR Camera Shoulder Rig QUICKSTART GUIDE



### CONDITIONS OF WARRANTY SERVICE

- Free service for one year from the day of purchase if the problem is caused by manufacturing errors.
- The components and maintenance service fee will be charged if the warranty period has expired.

Free Service will not be Provided in the Following Situations: (\* Even if the product is still within the warranty period.)

- Damage caused by abuse or misuse, dismantling, or changes to the product not made by the company.
- Damage caused by natural disaster, abnormal voltage, and environmental factors etc.

# ELE-DCFLY

## HDSLR Camera Shoulder Rig QUICKSTART GUIDE

What's Included:



☐ Handle Bar Grip



☐ Shoulder Mount



☐ 12" Rod



☐ D-Ring



☐ Friction Strip

☐ Allen Key



ikan

[www.ikancorp.com](http://www.ikancorp.com)

713-272-8822

# ELE-DCFLY

## HDSLR Camera Shoulder Rig QUICKSTART GUIDE



Insert 12" Rod  
into Shoulder  
Mount. Turn  
Thumb Screw  
until tight.



Shoulder  
mount can  
orientated to  
adjust to user.

# ELE-DCFLY

## HDSLR Camera Shoulder Rig QUICKSTART GUIDE



Insert Front end of 12" Rod into Handle Bar Grip. Tighter thumb screw until tight.



Mount Camera to Handle Bar grip using D-Ring to attach to the bar. Place Friction Strip on top of the Handle Bar grip to keep camera from spinning.



# ELE-DCFLY

## HDSLR Camera Shoulder Rig QUICKSTART GUIDE

Mount Camera to Handle  
Bar grip using D-Ring.

