

DIRECTIONS FOR KIRK BH SERIES BALL HEADS



Congratulations on your purchase of your new ball head. Using your new head is very simple.

Your ball head has three control knobs. Your main lock knob is the largest of the three. To use this knob, simply turn clockwise to tighten. To loosen, turn counter-clockwise while applying a slight inward pressure.




Figure 1




Figure 2




Figure 3



Figure 4

Your variable tension knob is the small knob on the opposite side of your main lock knob. To set the tension, you will need to first tighten the main lock knob tight (**Fig. 1**). Then tighten your tension knob tight (**Fig. 2**). Remember clockwise to tighten and counter-clockwise to loosen. Now you will need to loosen your main lock knob all the way (**Fig. 3**). Now start to loosen your tension knob (**Fig. 4**) until the amount of desired tension is set. At this point all you will have to do is loosen and tighten the main lock knob. If more tension is needed, simply tighten the tension knob. And if less is needed, just loosen the knob.



Figure 5

The last knob is for your panning base. This knob will lock the head from rotating 360 degrees. Simply turn the knob clockwise to tighten and counterclockwise to loosen. (**Fig. 5**)



We recommend cleaning your head every 4-6 weeks. To do this, loosen the main control knob and the tension knob. Move the ball into the 90 degree position. Now with a cloth lightly moistened with WD40 slowly turn the ball in the socket. When you're done with this process please wipe off any excess WD40 with a clean cloth. Also please avoid using any cleaner

other than WD40 and do not spray WD40 directly onto the ball. You can purchase WD40 at your local hardware or automotive store.

All knobs are captive, do not remove.

If you have any questions please call 260-665-3670

For custom mounting plates and ball head accessories, please visit our website www.KirkPhoto.com

The Kirk-Manufactured Product Warranty

The quality of every product manufactured by Kirk Enterprises is fully guaranteed to the original owner for five years from purchase date. If a Kirk-manufactured product fails because of a manufacturing or material defect, we will repair it or replace it at our option.

Please call Kirk Customer Support at 260-665-3670 Monday through Friday before returning any product.

Manufacturer's Warranties & Repairs

All products sold by Kirk Enterprises carry the full Manufacturer's Warranty, including those specially modified by Kirk, such as certain tripods and ball heads.

Call Kirk Customer Support at 260-665-3670 Monday through Friday for more information.

Our Science Will Improve Your Art.

KIRK enterprises

www.KirkPhoto.com

333 Hoosier Drive
Angola, IN 46703-9336
800-626-5074 • 260-665-3670
KirkPhoto@aol.com