



THANK YOU FOR PURCHASING THE KNEKT GP4 TRIGGER

THE KNEKT GP4 TRIGGER IS THE SUCCESSOR TO THE GP3+. IT IS THE MOST FEATURE RICH AND ROBUST TRIGGER WE HAVE EVER PRODUCED. THE GP4 INTEGRATES A NEW LATCH KEEPER DESIGN THAT MAKES IT NEARLY IMPOSSIBLE FOR YOUR HOUSING TO POP OPEN AND FLOOD IN HEAVY CONDITIONS. WE HAVE ADDED A STRUCTURAL REINFORCEMENT TAB TO THE UPPER HANDLE THAT INCLUDES AN ADDITIONAL 1/2-20 EXPANSION POINT. THERE ARE NOW 4 TOTAL. THERE IS A NEW AND INCLUDED ANTI-ROCK BACK BRACKET TO POSITION YOUR HOUSING PERFECTLY IN THE CAGE. IN ADDITION WE HAVE ADDED A CAGE FACE CUTAWAY THAT ALLOWS YOU TO USE THE KSD6 DOME PORT AND GOPRO'S FILTERS IN CONJUNCTION WITH THE TRIGGER. THE TRIGGER NOW EVEN COMES WITH A SURE GRIP TRIGGER SHEATH. BALANCED TO MATCH THE WEIGHT OF THE CAMERA THE GP4 IS DESIGNED TO GIVE YOU ONE-HANDED CONTROL OF YOUR GOPRO CAMERA'S VIDEO START/STOP AND STILL IMAGE SHUTTER RELEASE BUTTON. THE TRIGGER MECHANISM PROVIDES INSTANT SHUTTER REACTION AND SOLID, TACTILE FEEDBACK SO YOU CAN BE CONFIDENT THE CAMERA FIRED AND YOU GOT THE SHOT. OUR TRIGGER SYSTEMS PROVIDE A SIMPLE ONE-HANDED POINT AND SHOOT STYLE OF CONTENT ACQUISITION NOT POSSIBLE WHEN USING THE CAMERA ON ITS OWN OR ON A POLE. WITH THE CAMERA POSITIONED IN FRONT OF YOUR HAND YOU WILL EXPERIENCE IMPROVED STABILITY, CONTROL, AND SUBJECT ACQUISITION.

WHAT'S IN THE BOX


KNEKT GP4 TRIGGER, ANTI-ROCK BRACKET AND THUMB SCREW.




1 INSTALLATION INSTRUCTIONS

A. Hold bracket in one hand.

B. Align hole in bracket with 1/4-20 hole on either side of GP4 trigger.



C. Insert and partially tighten thumb screw.



D. Move bracket slightly out of the way and load GoPro into trigger.



E. Insert and tighten GoPro mounting screw and then tighten thumb screw to secure bracket.



F. GoPro is now fully secure and ready to be used in the heaviest conditions.



G. When done remove GoPro screw, slightly loosen bracket screw and remove GoPro. Anti-rock back bracket does not need to be fully removed and can be left attached to trigger.



Warranty

We want you to be happy with your KNEKT products and we do our best to build products that will last. We guarantee our trigger handles to be free of defects in materials and workmanship to the original buyer for 2 years. All other products are guaranteed for 12 months. This warranty does not cover loss or damage due to carelessness, obvious abuse, normal wear & tear or extend to any KNEKT product that has been modified in any way. Only KNEKT products are covered under this warranty and it does not extend to damage caused to other products used in conjunction with and or caused by your KNEKT products.

If you have a KNEKT product that you feel meets the above warranty guidelines please contact us so we can work together and make it right. If your warranty claim is deemed valid KNEKT will repair or replace the product less shipping costs. Send warranty inquires to info@goknekt.com

Proper Care of your KNEKT Products

With basic care your KNEKT products should last many years. After use in salt water or in any harsh environment your equipment needs to be thoroughly washed in fresh water. Make sure to wash out the hole where the thumbscrew locks the camera into the Trigger. If your KNEKT product gets really dirty mild dish washing soap and a little warm water should clean it right up. Never use glass cleaners, harsh chemicals or abrasives, as they will damage the products finish, especially your acrylic dome.

Sand and grit will get into every nook and cranny. We have designed our products to function in these harsh environments. The only exception is the KSD6 dome, it is not intended for harsh sandy environments. At times it may be difficult to remove your GoPro from the KNEKT Trigger. If this happens remove the thumb screw, run the entire assembly under fresh running water while moving the camera back and forth within the mounting slots. This should dislodge any sand and allow you to remove your camera housing.

Product Warning

The user of any product sold by KNEKT assumes all liability associated with the use of the product. The user agrees to hold KNEKT and its respective officers, directors and employees harmless from and against loss, damages, liabilities and expenses, including legal fees incurred in connection with any claim against KNEKT.

KNEKT is not liable for any loss, damages, personal injury or death associated with the use of their products.

Watch Tutorials

<http://www.knektusa.com/video/>