

AMP-IW4S INSTALLATION INSTRUCTIONS

Carton Contents:



AMP-IW4S
(Front View)



DECORA PLATE
(with two mounting screws)



REMOTE
CONTROL



SENSOR




24 VDC / 2.5A
POWER SUPPLY

Dimensions:

FRONT VIEW



SIDE VIEW



FRONT VIEW




Outputs / Controls:

FRONT INPUTS



- PUSH BUTTON VOLUME CONTROL (+/-) WITH GREEN LED STATUS
- AUDIO SOURCE SELECTION (A,B,C,D)
- BASS AND TREBLE CONTROL

INTERNAL INPUTS



AMP-IW4S INSTALL HINTS AND OPERATION



FRONT



(Remote Control)



INTERNAL / TOP



INTERNAL / BOTTOM

AMP-IW4S: Install Hints and Operation

- ☐ Installs in a standard NEMA rated 1-gang (or larger) electrical box with 3.0" minimum depth
- ☐ Must be turned 'On' via the 'SEL' front panel button or IR remote (Note: The LED's will not light until after the unit is turned 'On'.... terminating the power supply conductors will not turn it 'On')
- ☐ Front panel Bass and Treble POT adjustment is made manually via screwdriver (flat or Philips blade)
- ☐ Internal 'MO' (Master Override) page input 'Level' and 'Ducking' POT's are adjusted manually via screwdriver (flat or Philips blade)
- ☐ Retains its 'memory' of source and volume settings in case of power outage
- ☐ The front 'SEL' button ('Select') and IR remote control operate as follows;

On / Off:

- + Press and hold the 'SEL' button 3-4 seconds to activate On. The Power LED will light steady green
- + Press IR remote On/Off button (1 second or less. The Power LED will light steady green

Audio Source Input Selection (A,B,C,D):

- + After the unit is 'On' press the 'SEL' button to activate selection of audio sources (A,B,C,D). Once the source is selected stop pressing.
- + Press the IR remote buttons A,B,C or D. The selected source LED will light 'on'.

Volume + / -:

- + Press and HOLD the Up (+ ▲) or Down (- ▼) button until the desired level is achieved then release the button.
- + Press the IR remote Volume (+) or (-) buttons to the desired level with the LED indicating level

Mute:


- + Press the IR remote 'Mute Audio' button muting ALL audio from A,B,C,D inputs

CAUTION: When using the IR remote 'eye' please insure the AMP-IW4S front panel LED's are **VISIBLE** to the end user. This confirms the system is 'On', what Source (A,B,C,D) is selected and what Volume is set


*** Please strictly follow wiring instructions to prevent damage to the unit.***

AMP-IW4S INSTALLATION INSTRUCTIONS


Typical 'Audio' Connections



AMP-IW4S: AUDIO CHAIN SIGNAL FLOW DIAGRAM



AMP-IW4S: IR REMOTE CONTROL



OWI SPEAKER SYSTEM LIMITED WARRANTY REGISTRATION

(Save this portion for your records)

1. Your OWI Speaker System has been thoroughly tested and inspected at the factory. It is warranted for 1 year from date of purchase.
IT IS THE OWNERS' RESPONSIBILITY TO ESTABLISH THE DATE OF PURCHASE BY ACCEPTABLE EVIDENCE AT TIME SERVICE IS SOUGHT.
2. WHAT WE WILL PAY FOR AND WHAT YOU MUST PAY FOR:
OWI INC. will repair or replace unit(s) covered by this warranty, without charge to the consumer for labor or materials. YOU ARE RESPONSIBLE FOR ANY INSTALLATION OR REMOVAL CHARGES AND FOR ANY INITIAL SHIPPING CHARGES if the unit(s) must be shipped for warranty service. However, we will pay the return shipping charges to any destination within the U.S.A. if the repairs are covered by the warranty.
3. Any unit which in the judgment of OWI Inc. is defective or develops defects under normal use will be replaced or repaired without cost within the warranty period.
4. This warranty will be considered void if unit has been dropped, misused, abused, altered in any manner, overdriven with excessive amplification exceeding manufacturer's specification, improperly serviced or accidental damage.
5. OWI Inc. shall have no liability whatsoever for consequential damage. The sole responsibility and discretion of OWI Inc. under this warranty shall be limited to the repair of the product or replacement thereof.
6. IMPORTANT: This warranty is void unless the attached card is completed and mailed to OWI Inc. within 10 days following the date of purchase. Units must be sent to OWI Inc. or to the dealer where purchased.

OWI INCORPORATED
17141 Kingsview Ave
Carson, CA 90746-1207 USA

Date Purchased: _____
Model Number: _____
Serial Number: _____

(Keep this part for your record)

-----CUT AND MAIL-----



OWI INCORPORATED
17141 Kingsview Ave
Carson, CA 90746-1207 USA

LIMITED WARRANTY

Model Number: _____
Model Name: _____
Serial No. _____
Date of Purchase: Month: _____ Day _____ Year _____
Owner's Name: _____
Address: _____
City: _____ State _____ Zip _____
Dealer's Name: _____ City _____ State _____
Purchased from (please check one):
Video _____, Electronic _____, Mailorder _____, Mass Merchandiser _____, Installer _____
Others (please specify) _____
Remarks: _____