

speed ring

# INSTRUCTIONS



 **angler**<sup>™</sup>

## Congratulations on your purchase of an Angler Speed Ring!

This speed ring allows you to attach most major brands of softboxes to a strobe flash head quickly and easily. There are a variety of speed rings to fit most popular brands of strobes.

The outer rotating ring allows you to rotate the softbox 360°, and the ring's self-locking feature holds the softbox in whatever position suits your needs. The indexed flex rod holes make it easy to attach any type of softbox to the speed ring.

The Angler Speed Ring has all-metal construction for years of heavy-duty performance. The outer rotating ring is solid cast aluminum with precision machined rod holes for smooth assembly. The outer rotating ring also features two standard 3/8" tapped rod holes that can be used to adapt the speed ring to a variety of other products.

### Highlights

- ▶ All-metal construction
- ▶ Rotates 360 degrees
- ▶ Indexed flex rod holes
- ▶ Two 3/8"-16 female threaded receptors

### Contents

- ▶ Angler Speed Ring
- ▶ User Manual

### SPECIFICATIONS

Material	Aluminum alloy
Weight	1.1 lb. (0.5 kg)

## User Instructions

The indexed flex rod holes are a guide to assembling a variety of differently shaped softboxes: rectangular, square, strip (long, thin shape), narrow strip (longer, thinner shape), and octagonal.

- The flex rod holes labeled “A” are used when assembling a square or rectangular softbox.
- The holes labeled “B” are for a very narrow strip softbox.
- The holes labeled “C” are for a normal strip softbox.
- The holes labeled “8” are for assembling an octagonal softbox. For assembling the softbox, see the manufacturer’s instructions.

**Note:** Rubber feet on the tightening screws of the 7464-DYN speed ring may become overheated and melt when used with an Omni-light or any other continuous hot light. Remove the feet before use to prevent damage.

## Warnings

- ▶ Please read and follow these instructions, and keep this manual in a safe place.
- ▶ Do not attempt to disassemble or repair the equipment—doing so will void the warranty, and Angler will not be responsible for any resulting damage.
- ▶ Handle the unit with care.
- ▶ Clean the unit with a soft, dry cloth.
- ▶ Keep this unit away from children.
- ▶ Use only parts provided by the manufacturer.
- ▶ Make sure the item is intact and that there are no missing parts.
- ▶ All photos are for illustrative purposes only.

## One Year Limited Warranty

This Angler product is warranted to the original purchaser to be free from defects in materials and workmanship under normal consumer use for a period of one (1) year from the original purchase date or thirty (30) days after replacement, whichever occurs later. The warranty provider's responsibility with respect to this limited warranty shall be limited solely to repair or replacement, at the provider's discretion, of any product that fails during normal use of this product in its intended manner and in its intended environment. Inoperability of the product or part(s) shall be determined by the warranty provider. If the product has been discontinued, the warranty provider reserves the right to replace it with a model of equivalent quality and function.

This warranty does not cover damage or defect caused by misuse, neglect, accident, alteration, abuse, improper installation or maintenance. EXCEPT AS PROVIDED HEREIN, THE WARRANTY PROVIDER MAKES NEITHER ANY EXPRESS WARRANTIES NOR ANY IMPLIED WARRANTIES, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. This warranty provides you with specific legal rights, and you may also have additional rights that vary from state to state.

To obtain warranty coverage, contact the Angler Customer Service Department to obtain a return merchandise authorization ("RMA") number, and return the defective product to Angler along with the RMA number and proof of purchase. Shipment of the defective product is at the purchaser's own risk and expense.

For more information or to arrange service, visit [www.anglerlights.com](http://www.anglerlights.com) or call Customer Service at 212-594-2353.

Product warranty provided by the Gradus Group.  
[www.gradusgroup.com](http://www.gradusgroup.com)

Angler is a registered trademark of the Gradus Group.  
© 2015 Gradus Group LLC. All Rights Reserved.



GG1