



PBS-XS

Compact X-Style Piano Bench

Owner's Manual



Introduction

Thank you for choosing the Auray PBS-XS Piano Bench. This X-style, foldable, lightweight piano bench is a sturdy and durable solution for keyboard players at home, in the studio, or on the go. It adjusts to three height positions in one-inch increments, and the 2-inch leather seat provides comfort through many hours at the keyboard. The X-style construction allows the PBS-XS to fold flat for easy storage or travel and assures easy setup.

Warnings

This product has been tilt-stability tested. Auray is not responsible for injury due to improper use. Bench must be on a level surface with all legs touching the surface at the same time.

- Please read and follow these instructions, and keep this manual in a safe place.
- Make sure that this product is intact and that there are no missing parts.
- Make sure all parts are secure before using.
- All photos are for illustrative purposes only.

Overview


C brackets (2) 1

Locking knobs (2) 2

Threaded knob 3

Carriage bolt 4

Washers (2) 5



Instructions

Setup

1. Place the piano bench upside down on a stable surface.
2. Place the crossbeam of the non-attached leg into the C-brackets **1** and tighten the two locking knobs. **2**
3. Stand the bench upright and place it on a flat surface.



Adjusting the height

1. Unscrew the threaded knob and remove the carriage bolt and washers.
2. Align the two corresponding holes of the two legs at the desired height and hold the washer between them.
3. Insert the carriage bolt into the square hole of the leg, through the washer and corresponding hole of the other leg. Make sure the carriage bolt is fully inserted and that the head of the bolt is flush against the leg. **3**
4. Attach the washer and threaded knob to the end of the bolt and securely tighten.



Note: The holes of each leg must correspond. If they don't, the bench will not be level.

Specifications

Height: 18.75" – 20.75" (47.6 – 52.7 cm)

Width: 12" (30.5 cm)

Length: 24" (61 cm)

Weight: 8.25 lbs. (3.74 kg)

Seat size: 17" × 12" (42.2 × 30.5 cm)

Cushion depth: 2" (5.1 cm)

Weight Capacity: Up to 200 lbs. (90.7 kg)

One-Year Limited Warranty

This AURAY product is warranted to the original purchaser to be free from defects in materials and workmanship under normal consumer use for a period of one (1) year from the original purchase date or thirty (30) days after replacement, whichever occurs later. The warranty provider's responsibility with respect to this limited warranty shall be limited solely to repair or replacement, at the provider's discretion, of any product that fails during normal use of this product in its intended manner and in its intended environment. Inoperability of the product or part(s) shall be determined by the warranty provider. If the product has been discontinued, the warranty provider reserves the right to replace it with a model of equivalent quality and function.

This warranty does not cover damage or defect caused by misuse, neglect, accident, alteration, abuse, improper installation or maintenance. EXCEPT AS PROVIDED HEREIN, THE WARRANTY PROVIDER MAKES NEITHER ANY EXPRESS WARRANTIES NOR ANY IMPLIED WARRANTIES, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. This warranty provides you with specific legal rights, and you may also have additional rights that vary from state to state.

To obtain warranty coverage, contact the Auray Customer Service Department to obtain a return merchandise authorization ("RMA") number, and return the defective product to Auray along with the RMA number and proof of purchase. Shipment of the defective product is at the purchaser's own risk and expense.

For more information or to arrange service, visit www.aurayaudio.com or call Customer Service at 212-594-2353.

Product warranty provided by the Gradus Group.
www.gradusgroup.com

AURAY is a registered trademark of the Gradus Group.
© 2014 Gradus Group LLC. All Rights Reserved.



GG1