

The elvid logo consists of the word "elvid" in a lowercase, sans-serif font, colored white. It is positioned inside a yellow rectangular box with rounded corners. The background of the entire page is dark gray with large, flowing, curved shapes in varying shades of gray and yellow, creating a modern, abstract aesthetic.

elvid

OptiView 150

OV-150

LCD VIEWFINDER

.....

**USER
MANUAL**





INTRODUCTION

Thank you for choosing the Elvid OptiView 150. This LCD viewfinder provides a clear 3x magnification for a 3-inch LCD screen with 4:3 or 3:2 aspect ratio that's built into most DSLR cameras. The magnification creates a larger than normal view of the image on your device's screen, facilitating fine detail focusing. Additionally, this easy to install accessory blocks outside light, creating ideal viewing conditions for video and photography users.

PRECAUTIONS

- Please read and follow these instructions.
 - Keep this manual in a safe place.
 - The OptiView's lens acts the same as a magnifying glass, intensifying heat from the sun during prolonged exposure to direct sunlight.
- Remove the viewfinder when not in use, as the camera's LCD may be damaged by the magnified light.
- Do not use the viewfinder's included lanyard to support your camera. Use your camera strap to support the camera.

- Handle this product with care.
- Clean this product with a soft, dry cloth.
- Use only parts provided by the manufacturer.
- Make sure everything is secure before proceeding.
- Make sure that this product is intact and that there are no missing parts before use.

TABLE OF CONTENTS


Product Contents	7
Overview	8
Features.....	9
Using the Optiview	10-15
Specifications	16
Notes.....	17
Warranty	18-19

PRODUCT CONTENTS



- 3x LCD Viewfinder
- 17" lanyard
- User manual
- Plastic mounting frame/screen protector with optical glass
- Warranty

OVERVIEW



FEATURES

- Turns your camera's LCD screen into a magnified viewfinder
- Facilitates fine detail focusing
- Supports most 3" LCD screens with a 4:3 or 3:2 aspect ratio
- Blocks out ambient light for clear image viewing
- Easy to install and remove
- Flips up to reveal your camera's LCD screen
- Includes a LCD screen-protecting mounting frame with optical glass
- Lanyard included for hands-free carrying
- Eyecup compatible with left or right eye

USING THE OPTIVIEW

1. Clean your LCD screen with a soft, dry cloth.
2. Turn on your LCD screen. The heat from the camera will promote adhesion of the LCD mounting frame.
3. Remove the plastic cover on the adhesive side of the screen protector/mounting frame and apply its adhesive side to your camera's LCD screen. Push down on the screen cover to secure. (Fig. 1)

(Fig. 1)



USING THE OPTIVIEW (CONTINUED)

4. Place a light object (like a hardcover book) on the mounting frame overnight to fully secure it to the camera's LCD screen.
5. Once securely attached, remove the plastic film from the outside of the mounting frame.
6. With the lanyard loop and securing clip oriented downward, connect and secure the OptiView to your mounting frame. You will hear a click sound when the viewfinder is securely attached. (Fig. 2)

(Fig. 2)



USING THE OPTIVIEW (CONTINUED)

7. With the camera on, look at the image on the LCD screen through the OptiView. If out of focus, use the diopter ring.
8. To view the LCD screen without magnification, simply lift the viewfinder upward to expose the camera's screen. (Fig. 3)
9. To remove the OptiView from the camera, push the button on the bottom of the viewfinder and gently pull it from the mounting frame. (Fig. 4)

(Fig. 3)



(Fig. 4)



SPECIFICATIONS	
Magnification	3x
Support	Most DSLR cameras with a 3-inch, 4:3 or 3:2 aspect ratio LCD screen
Diopter	3±
Lanyard Length	17 inches
Dimensions	3.5" x 2.8" x 2.2" (8.9 x 7.1 x 5.5 cm)
Weight	4 oz. (113.3 g)

NOTES

ONE-YEAR LIMITED WARRANTY

This Elvid product is warranted to the original purchaser to be free from defects in materials and workmanship under normal consumer use for a period of one (1) year from the original purchase date or thirty (30) days after replacement, whichever occurs later. The warranty provider's responsibility with respect to this limited warranty shall be limited solely to repair or replacement, at the provider's discretion, of any product that fails during normal use of this product in its intended manner and in its intended environment. Inoperability of the product or part(s) shall be determined by the warranty provider. If the product has been discontinued, the warranty provider reserves the right to replace it with a model of equivalent quality and function.

This warranty does not cover damage or defect caused by misuse, neglect, accident, alteration, abuse, improper installation or maintenance. EXCEPT AS PROVIDED HEREIN, THE WARRANTY PROVIDER MAKES NEITHER ANY

EXPRESS WARRANTIES NOR ANY IMPLIED WARRANTIES, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. This warranty provides you with specific legal rights, and you may also have additional rights that vary from state to state.

To obtain warranty coverage, contact the Elvid Customer Service Department to obtain a return merchandise authorization ("RMA") number, and return the defective product to Elvid along with the RMA number and proof of purchase. Shipment of the defective product is at the purchaser's own risk and expense.

For more information or to arrange service, visit www.elvidcinema.com or call Customer Service at 212-594-2353.

www.elvidcinema.com



Product warranty is provided by the Gradus Group. www.gradusgroup.com
Elvid is a registered trademark of the Gradus Group.
© 2015 Gradus Group LLC. All Rights Reserved.

GG1

