

The logo for elvid, consisting of the word "elvid" in a lowercase, sans-serif font, enclosed within a yellow rounded rectangular border.

elvid

MONITOR BATTERY PLATE

For Sony L-Series, Canon LP-E6,
and Panasonic D28 batteries

USER MANUAL

FOR: FBP-F970 / FBP-LPE6 / FBP-PD28

INSTRUCTIONS

Installing the Battery Plate

Before proceeding, remove the battery from your Elvid monitor, and make sure that the monitor is unplugged and turned off.

1. Use a Phillips-head screwdriver (not included) to unscrew and remove your Elvid monitor's existing battery plate, including the wires connecting it to the back of the monitor.
2. Place the Elvid FBP battery plate's red wire on the positive terminal, and the black wire on the negative terminal. Insert the two included big screws into the terminals, and use a Phillips-head screwdriver to fasten them until fully tightened. Be careful not to overtighten.
3. Position the FBP battery plate with the open side facing the top of the monitor. Align the battery plate's screw holes with the monitor's screw holes. Make sure the battery plate covers the red and black wires completely and that no part of the wires is exposed.

4. Insert the four included small screws into the screw holes and use a Phillips-head screwdriver to fasten them until fully tightened. Be careful not to overtighten.



Specifications

Compatibility

FBP-F970: Sony L-Series batteries

FBP-LPE6: Canon LP-E6 batteries

FBP-PD28: Panasonic D28 batteries

Elvid WCM-758G, WCM-758DVR,
and OCM-7B-D monitors

Dimensions (W × H × D): 2.4" × 3.8" × 0.6"
(6.1 × 9.7 × 1.5 cm)

Weight: 0.7 oz. (21 g)

ONE-YEAR LIMITED WARRANTY

This Elvid product is warranted to the original purchaser to be free from defects in materials and workmanship under normal consumer use for a period of one (1) year from the original purchase date or thirty (30) days after replacement, whichever occurs later. The warranty provider's responsibility with respect to this limited warranty shall be limited solely to repair or replacement, at the provider's discretion, of any product that fails during normal use of this product in its intended manner and in its intended environment. Inoperability of the product or part(s) shall be determined by the warranty provider. If the product has been discontinued, the warranty provider reserves the right to replace it with a model of equivalent quality and function.

This warranty does not cover damage or defect caused by misuse, neglect, accident, alteration, abuse, improper installation or maintenance. EXCEPT AS PROVIDED HEREIN, THE WARRANTY PROVIDER MAKES NEITHER ANY EXPRESS WARRANTIES NOR ANY IMPLIED WARRANTIES, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. This warranty provides you with specific legal rights, and you may also have additional rights that vary from state to state.

To obtain warranty coverage, contact the Elvid Customer Service Department to obtain a return merchandise authorization ("RMA") number, and return the defective product to Elvid along with the RMA number and proof of purchase. Shipment of the defective product is at the purchaser's own risk and expense.

For more information or to arrange service, visit www.elvidcinema.com or call Customer Service at 212-594-2353.

Product warranty is provided by the Gradus Group.
www.gradusgroup.com

Elvid is a registered trademark of the Gradus Group.
© 2015 Gradus Group LLC. All Rights Reserved.

www.elvidcinema.com

