

ETY•kids³[™]

Safe-Listening
Headset + Earphones for Kids



Made for
iPod iPhone iPad

ETY•kids⁵[™]

Safe-Listening
Earphones for Kids



User Manual English

Caution

In rare instances an eartip may come off in the ear canal when removing the earphone. If this should occur and the eartip cannot be easily removed, it is recommended that you promptly contact an audiologist or other medical professional. A professional can use blunt tweezers to remove the eartip.

Consult an audiologist or physician if you have excessive ear wax, difficulty inserting the eartips, or discomfort after prolonged use.

Etymotic earphones exclude most external sounds. It is unsafe to use in-ear earphones while operating a motorized vehicle, operating machinery, bicycling or jogging, because you may not be alerted to potential danger.

Do not use at excessively loud levels. Research confirms that earphones that seal the ear canal allow listeners to listen at safer levels. Noise-induced hearing loss is a function of exposure time, the average sound level and the peak of very loud sounds. A sealed eartip and lower listening levels allow for longer periods of safe listening.

ETY•Kids are engineered for safe sound output, assuming 4 hours or less per day listening at full volume.



WARNING: CHOKING HAZARD - Small parts. Not for children under 3 years

In the box

- ek series earphones or headset + earphones
- Assortment of ACCU-Fit™ eartips
- Pouch

ek5 earphones



- A. Earphones
- B. Shirt clip
- C. Cable slider
- D. 3.5 mm stereo plug

ek3 headset + earphones



- A. Earphones
- B. Shirt clip
- C. Cable slider
- D. 3-button control/mic
- E. 3.5 mm, 4-contact phone + stereo plug

Selecting an Eartip



The eartips that are most comfortable are the best choice, but they should seal well in the ears for best noise isolation and sound quality.

When changing eartips make sure the eartip fits securely on the stem of the earphone.



correct



incorrect

Cleaning and Replacing Eartips

Over time eartips may lose their elasticity. For best performance and retention, replace 3-flange eartips every 3-6 months. Replace foam and glider eartips regularly.


To clean 3-flange eartips:

1. Remove eartip from the earphone.
2. Clean with water and mild soap.
3. Dry the eartip before placing it back on the earphone.

Proper Insertion

Important: Sound quality, full bass response and noise isolation all depend on a good eartip seal in the ear canal.

See a video demonstration at www.etymotic.com.



- Carefully insert the earphone while pulling up and out on the back of the ear.
- Twist the earphone up into the ear canal while inserting, until outside noise is blocked out.
- **3-flange eartip:** Moistening eases insertion.
- **Glider eartip:** Simply push into ear canal.

Removal

Remove earphones *slowly* with a twisting motion to gradually break the seal. Do not pull on the cable to remove the earphones.

ek3 Apple 3-Button Control

Listening to Music*

Play/Pause

While listening to music:

- Press the middle button **once** to Pause music.
- Press the middle button again to resume music.

*Additional functionality of the center button varies among Apple devices.



Track Forward

While listening to music:

- Press the middle button **twice** rapidly to track **forward**.
- Press the middle button **three times** rapidly to track **back**.

Answering a Call

Music automatically mutes and pauses for an incoming call.

To answer a call while listening to music:

- Press the middle button to answer the call.

Disconnecting a Call

- Press the middle button to disconnect the call.
- Music automatically resumes.

Warranty

Etymotic Research, Inc. warrants this product against defects in material or workmanship for a period of one year from the date of original purchase from an authorized Etymotic distributor or reseller.

Etymotic will repair or replace the defective product at its option if returned within the warranty period to our designated service facility. This warranty is in lieu of all other warranties, expressed or implied, including, but not limited to, any implied warranty of merchantability or fitness for a particular purpose.

ETY•kids³
Safe-Listening
Headset + Earphones for Kids

ETY•kids⁵
Safe-Listening
Earphones for Kids

ETYMOTIC RESEARCH INC.

www.etymotic.com • 1-888-389-6684 • 847-228-0006

©2012. etykids3, etykids5, ACCU-Technology, and ACCU-Fit are trademarks of Etymotic Research, Inc.
ER050511