

REMOVING THE ADAPTER

New-FD Bayonet Mount

Press the lens release on your lens and turn to remove adapter

FD/FL Breech-Mount

Turn the ring on the lens until adapter is removed

FotodioX
F O T O D I O X

FD Lens Adapter

Instruction Manual

CONTACT US:

For Information Regarding this and more of our products, please contact us:

E-mail: info@fotodiox.com

Phone: 847.201.4623

www.fotodiox.com

3805 Hawthorne Ct.
Waukegan IL, 60087

We're also on:



*Lens not included

www.fotodiox.com

MOUNTING THE ADAPTER


- 1 Before mounting the adapter on any FD-Mount type, (Regular Lock mount or Breech-Lock Mount) you must place the adapter ring on Install




New-FD Bayonet Mount

- 2 Set your lens to any aperture except for auto (bayonet mount only)

Bayonet mounts are identified by a red dot next to the lens release button



FD/FL Breech-Mount




Breech-Lock Mounts are identified by this black or silver ring

- 3 Match the lens and adapter markings and turn adapter for bayonet mount. Turn ring on lens for breech mount until securely locked

OPERATING THE ADAPTER

If you'd like to operate the lens aperture with the adapter; on your lens, set the aperture to the smallest opening and use the adapter ring



If you'd like to operate the lens aperture with the lens; place the adapter ring on the small aperture icon and control the aperture on the lens



MACRO PHOTOGRAPHY

Unscrew the glass holder and remove glass for macro photography.

Store Glass in a safe place to avoid scratches

