

Where There's A Jam,  
There's A Party!™



[www.jamaudio.com](http://www.jamaudio.com)

USER GUIDE AND WARRANTY INFORMATION

HX-P240A

READ UP.

PARTY DOWN.

#### PAIRING 1 JAM PLUS SPEAKER

1. Turn speaker over and move speaker mode switch to Mono.
2. Press and hold the power button for 5 seconds.
3. Follow instructions of your device to pair the unit.
4. Pair your device with the speaker by selecting Jam Plus from your Bluetooth listings on your device or selecting YES.
5. Press play on your device and use the controls on the unit to adjust desired volume.



#### PAIRING 2 JAM PLUS SPEAKERS TOGETHER

1. Turn the speaker over and move the speaker mode switch to L.
2. Turn the 2nd speaker over and move the speaker mode switch to R.
3. Press and hold the power button for 5 seconds on the 1st speaker.
4. Press and hold the power button for 5 seconds on the 2nd speaker.
5. Speakers will begin to pair together automatically.
6. Pairing process can take up to 30 seconds. When you hear a tone and the JAM2 indicator light is solid white, you may pair your device.
7. Follow your device instructions to pair the speakers.
8. Pair your device with the speakers by selecting Jam2 from your Bluetooth listings on your device or selecting YES.



#### HEY, HAVE WE SEEN YOU HERE BEFORE?

Register your speaker at [www.jamaudio.com](http://www.jamaudio.com). Information about where you bought it and how you're using it is like gold for the people who make these speakers. Do them a solid, will ya?

Por manual de instrucciones e información de garantía en español visítenos en [www.jamaudio.com](http://www.jamaudio.com)

There are lots of cool Jam speakers. Check them all out at [www.jamaudio.com](http://www.jamaudio.com)

#### PACKAGE CONTENTS



Speaker



User Manual



Charging Cord




Language Selector Pin

#### JUST CHARGE IT

Charging the speaker is so easy you've probably figured it out by now, but just in case, you've got two options: you can charge it using your computer or a wall outlet.

1. The cord that came with the speaker—the one with the USB on one end and the Micro USB on the other—is made to work with your computer.




2. If you want to use the wall outlet, you'll need to pick up a power cord with a Micro USB the next time you're at the store, or use any USB AC adapter, including the one for your cell.



Now go get ready for an epic night while your speaker does too. It needs about 3 hours to be fully charged for 6 hours of party time.

#### CONTROL YOUR DESTINY...OR AT LEAST YOUR SPEAKER

1. This is the power button, press and hold for 5 seconds to power on
2. Speaker Mode switch
3. The power cord goes here
4. Here's where you use a mini jack cord to hook it up old school
5. It speaks too. Toggle between languages here
6. Language Selector Pin
7. Reset
8. Check out how much juice is in the battery
9. Turn the music down (Wait, why do you need to turn it down?)
10. Push it to play, push it again to pause
11. Turn the music up
12. This light lets you know when Bluetooth is paired
13. Jam<sup>2</sup> Light



#### BLUETOOTH® CONNECTION: IT'S A SETUP

Like any amazing couple, this one starts with a connection—one between your device and the speaker's *Bluetooth*.

Here's how it works:

1. We know you're probably going to think, "derp" with this one, but we have to say it: Make sure the smartphone, tablet or computer you want to hook up to the speaker has *Bluetooth*. (There. We got that out of the way.)
2. Turn on the speaker (press and hold for 5 seconds) and look for the little blinking light.
3. Do whatever your device needs you to do on its end. (We don't know what you're using. We're not spies.)
4. Look for JAM PLUS in your device's *Bluetooth* list or click YES—whatever pops up on your device—and BAM! you're connected.
5. Now hit PLAY on your speaker and crank it up—or down if you're lame.

You're probably only going to have to do this once, unless your device goes through a major I-just-dropped-it-in-the-pool kind of reboot. The device and *Bluetooth* will find each other every time just as long as the speaker is set to *Bluetooth* and your device's *Bluetooth* is, you know—on.

If you're connecting to a computer, you may have some extra steps on that end. You'll have to get that information from the computer company.

Depending on your device you may be prompted to enter a pairing code. If prompted enter "0000" as the code.

Press and hold the PLAY/PAUSE button for 5 seconds to activate pairing mode.

Note: If you turn on your Jam Plus but haven't started the party yet, it will automatically power off after 2 minutes of unpaired inactivity.

Note: You should never have to do this, but in the event the speaker controls are not operable, press the reset button to reset the speaker.

## ALLOW US TO SHED SOME LIGHT

	What It Looks Like	What it Means	
CHARGE	Flashing RED	Low Battery	
	RED (while plugged in)	Charging	
	LED Off (fully charged)	Ready to Party	
	Quick Flash BLUE	Pairing Mode	
	Slow Flash BLUE	Connected	
	RED	Line-in Mode	

## SURROUND YOURSELF IN STEREO

Pairing two JAM Plus speakers is super easy:

1. Turn over one of the speakers—either one—and switch it to L. (Don't power it up quite yet.)
2. Now switch the other speaker to R.
3. OK, now turn on the speakers by holding each of the bottom power buttons for 5 seconds.
4. Stand (or sit) in awe as your speakers start the pairing process. It only takes 30 seconds or less.
6. Once you hear the tone and see the jam2 light is solid white, the speakers are paired.
7. Do what you've got to do on your device to set up the Bluetooth connection. Like a lot of married couples, you'll find them under one name—Jam2.

Note: When a call is coming in jam2 mode, only the master (left speaker) can answer the call.

## HOOKING UP OLD SCHOOL AUDIO, JACK

1. Plug one end of the cord into the speaker and the other into the headphone jack on your device.
2. Turn on the speaker.
3. Hit PLAY on your device and crank it up—or down if you're lame.

You'll have to play and pause the music from your device, not your speaker.

No problem. You're there anyway, right?

## HELLO? SPEAKERPHONE? YES!

When friends call asking to join the party—and you know they will—answer the phone without disconnecting from your JAM Plus Yes, that's right. Your speaker is a speakerphone too. How amazing is that?

Here's how it works:

1. Make sure your phone and speaker are connected through *Bluetooth*.
2. Answering and ending a call works the same way: simply click the PLAY/PAUSE button on your Plus.
3. If you'd rather not talk, hold down the PLAY/PAUSE button on your Plus for three seconds to ignore the call.

**THE COOLEST PART:** The Plus knows when a call is coming in and pauses the music before ringing. When you hang up, the music starts where it left off—and so does the party. If it's you making the call, just start dialing from your phone, and the Plus automatically does its hands-free thing. Isn't it refreshing to know your speaker totally gets you?

## THE VOICE FROM WITHIN

When your JAM Plus isn't rocking out, it can tell you all sorts of things it's doing: when it's powering on, ready to pair, paired, maximum volume, charging, incoming call, call ended, call rejected, powering off.

Just like the global gadget it is, your speaker toggles between several languages or no language at all. Your speaker can parlay with you in English, Spanish, French, or Portuguese. But, making the change between language and tone is as simple as poking a paperclip, safety pin, or the pin included into the small hole on the bottom. Click through until the speaker starts speaking your language.

## COMING CLEAN

A soft, dry towel is all you need to clean off your speaker. Using water, harsh cleaners or anything else only starts messing with the mechanics inside. So, yeah, don't do it.

## STUFF THE GOVERNMENT MAKES US SAY

### FCC Disclaimer:

Note: This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Note: Changes or modifications not expressly approved by HMDX could void the user's authority to operate this equipment.

## ONE YEAR LIMITED WARRANTY

For detailed Warranty Instructions and Information visit:

<http://www.jamaudio.com/customer-support/warranty-1yr>

To obtain warranty service on your Jam product, contact a Consumer Relations Representative by telephone at 1-888-802-0040 or email [cservice@jamaudio.com](mailto:cservice@jamaudio.com) for assistance. Please make sure to have the model number of the product available. Representatives are available 8:30am - 7:00pm EST Monday-Friday.

## STUFF OUR LAWYERS MAKE US SAY

### READ ALL INSTRUCTIONS BEFORE USING

- **WARNING:** Do not place speakers too close to ears. May cause damage to ear drums, especially in young children.
- Use this product only for its intended use as described in this manual. Do not use attachments not recommended by HMDX.
- HMDX is not liable for any damage caused to Smartphones, iPod/MP3 player or any other device.
- Do not place or store this product where it can fall or be dropped into a tub or sink.
- Do not place or drop into water or any other liquid.
- Not for use by children. **THIS IS NOT A TOY.**
- Never operate this product if it has a damaged cord, plug, cable or housing.
- Keep away from heated surfaces.
- Only set on dry surfaces. Do not place on surface wet from water or cleaning solvents.

## A MESSAGE FROM THE ENVIRONMENT

### WARNING:

This product has an internal, non-replaceable lithium battery. Please dispose in accordance with your local, state, province and country guidelines.

This product contains small parts that may present a choking hazard for young children.

**CAUTION:** All servicing of this product must be performed by authorized Jam Audio Service Personnel only

Note: The most up-to-date version of the Jam Plus User Guide can always be found at [www.jamaudio.com](http://www.jamaudio.com)

Por manual de instrucciones e información de garantía en español visítenos en [www.jamaudio.com](http://www.jamaudio.com)

© 2013–2014 HMDX. All Rights Reserved.  
IB-HXP240A

Follow JamAudio on Facebook, Twitter,  
Spotify & Soundcloud to feed your Jam with  
weekly playlists of hot new music.