


impact™



Grid for Quikbox
INSTRUCTIONS

Attaching The Grid



Remove the grid from the bag and spread it out completely.



With the touch-fastener edge facing outwards (towards the front of the Quikbox), attach the top edge first.



Continue attaching the two sides using the touch fastener, then attach the bottom.



There will be a small space between the two grid edges to accommodate the reflective panels on the Quikbox.

Removing The Grid

- 5** Remove the grid by grasping a corner and gently pulling it off the Quikbox.



6 To fold the grid, grasp two opposing corners and pull them in opposite directions. The grid will now be long and flat.



7 Either roll or fold the grid in thirds and replace in the carry bag.



Quikbox with grid



Quikbox without grid

One-Year Limited Warranty

This IMPACT product is warranted to the original purchaser to be free from defects in materials and workmanship under normal consumer use for a period of one (1) year from the original purchase date or thirty (30) days after replacement, whichever occurs later. The warranty provider's responsibility with respect to this limited warranty shall be limited solely to repair or replacement, at the provider's discretion, of any product that fails during normal use of this product in its intended manner and in its intended environment. Inoperability of the product or part(s) shall be determined by the warranty provider. If the product has been discontinued, the warranty provider reserves the right to replace it with a model of equivalent quality and function.

This warranty does not cover damage or defect caused by misuse, neglect, accident, alteration, abuse, improper installation or maintenance. EXCEPT AS PROVIDED HEREIN, THE WARRANTY PROVIDER MAKES NEITHER ANY EXPRESS WARRANTIES NOR ANY IMPLIED WARRANTIES, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. This warranty provides you with specific legal rights, and you may also have additional rights that vary from state to state.

To obtain warranty coverage, contact the Impact Customer Service Department to obtain a return merchandise authorization ("RMA") number, and return the defective product to Impact along with the RMA number and proof of purchase. Shipment of the defective product is at the purchaser's own risk and expense.

For more information or to arrange service, visit www.impactstudiolighting.com or call Customer Service at 212-594-2353.



Product warranty provided by the Gradus Group.

www.gradusgroup.com

IMPACT is a registered trademark of the Gradus Group.

© 2014 Gradus Group LLC. All Rights Reserved.