



# Quikbox Micro Softbox INSTRUCTIONS

# Introduction

Thank you for choosing the Impact Quikbox Micro On-Camera Softbox. This convenient 9 × 9 in. light modifier slips onto an on-camera flash in seconds, transforming the light produced by the flash from harsh to soft and diffused. The reflective silver interior minimizes light loss, while the included front diffusion screen and internal baffle make it possible to customize the degree of diffusion for the effect you desire.

The Quikbox Micro On-Camera Softbox is ideal for portraits, weddings, events, or any time you photograph people with your on-camera flash. It's compatible with most on-camera flashes, including the Nikon SB-910 and the Canon 600EX-RT. Touch-fastener straps make it fast and easy to mount and dismount the softbox with any flash.

## Precautions

- Please read and follow these instructions, and keep this manual in a safe place.
- Keep this unit away from liquids and any flammable gases.
- Handle the unit with care.
- Clean the unit with a soft, dry cloth.
- Keep this unit away from children.
- Use only parts provided by the manufacturer.
- Make sure the item is intact and that there are no missing parts.
- All photos are for illustrative purposes only.

## Contents include:

- Impact EBO-0699 Quikbox Micro Softbox
- Front diffuser
- Internal baffle
- Carrying case
- User manual
- One-Year Limited Warranty

# Using the Quikbox Micro On-Camera Softbox



1. Remove the softbox, front diffuser and internal baffle from the carrying sleeve.
2. Pull the softbox open to form a square shape.
3. Note that the largest of the panels is the top of the softbox.



4. Position the flash head so that it will point straight ahead when mounted on the camera.

# Using the Quikbox Micro On-Camera Softbox



5. Before attaching your flash to a camera, insert the front of the flash head through the elasticized opening in the rear of the softbox. Leave the back end of the flash head outside the rear of the softbox.



6. Attach the inner set of touch-fastener strips one on top of the other across the pivoting portion of the flash head until they're secure across the back of the flash.



7. Close the outer set of touch-fastener strips tightly over the inner set of touch-fastener strips.



8. There are two pieces of diffusion material included: the small internal baffle and the larger front diffuser.
9. To mount the internal baffle, insert it into the front of the softbox and attach the four corners of the baffle to the four touch-fastener tabs inside the softbox. Adjust the touch-fasteners so that the baffle spreads evenly across the softbox.

## Using the Quikbox Micro On-Camera Softbox



10. To mount the front diffuser, position it so that the touch-fastener strip faces the interior of the softbox, then press the strip along one side of the front of the softbox. Continue by pressing another side of the diffuser against a side of the softbox, and follow through until all four sides are attached to the softbox.



11. Mount the flash normally on the camera's hot shoe.

**Note:** You may use the Quikbox Micro Softbox with the internal baffle alone, the front diffuser alone, both the baffle and the diffuser together, or without either the baffle or the diffuser—depending on the effect you desire. You may also leave the diffuser, the baffle, or both in place when collapsing the softbox for storage.

### *Specifications:*

- Dimensions (WxHxD): Overall: 11 × 10.75 × 9 in. (28 × 27 × 23 cm)  
Front diffuser: 9 × 9 in. (23 × 23 cm)
- Weight: 12 oz. (340.2 g)

#### One-Year Limited Warranty

This IMPACT product is warranted to the original purchaser to be free from defects in materials and workmanship under normal consumer use for a period of one (1) year from the original purchase date or thirty (30) days after replacement, whichever occurs later. The warranty provider's responsibility with respect to this limited warranty shall be limited solely to repair or replacement, at the provider's discretion, of any product that fails during normal use of this product in its intended manner and in its intended environment. Inoperability of the product or part(s) shall be determined by the warranty provider. If the product has been discontinued, the warranty provider reserves the right to replace it with a model of equivalent quality and function.

This warranty does not cover damage or defect caused by misuse, neglect, accident, alteration, abuse, improper installation or maintenance. EXCEPT AS PROVIDED HEREIN, THE WARRANTY PROVIDER MAKES NEITHER ANY EXPRESS WARRANTIES NOR ANY IMPLIED WARRANTIES, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. This warranty provides you with specific legal rights, and you may also have additional rights that vary from state to state.

To obtain warranty coverage, contact the Impact Customer Service Department to obtain a return merchandise authorization ("RMA") number, and return the defective product to Impact along with the RMA number and proof of purchase. Shipment of the defective product is at the purchaser's own risk and expense.

For more information or to arrange service, visit [www.impactstudiolighting.com](http://www.impactstudiolighting.com) or call Customer Service at 212-594-2353.



Product warranty provided by the Gradus Group.  
[www.gradusgroup.com](http://www.gradusgroup.com)

IMPACT is a registered trademark of the Gradus Group.  
© 2014 Gradus Group LLC. All Rights Reserved.

To see all of our lighting equipment,  
please visit our website.



[www.impactstudiolighting.com](http://www.impactstudiolighting.com)