



- a L-Bracket
- b Camera Strap Connector
- c Allen Screw
- d $\frac{5}{32}$ " Allen Wrench (large)
- e $\frac{1}{8}$ " Allen Wrench (small)

STEP ONE

1. Attach **L-BRACKET** loosely to the bottom of the camera with $\frac{5}{32}$ " **ALLEN WRENCH** (provided).

STEP TWO

2. Insert **CAMERA STRAP CONNECTOR** into the top of the **L-BRACKET**.

STEP THREE

3. Insert the **ALLEN SCREW** through the **CAMERA STRAP CONNECTOR** and into the top of the **L-BRACKET**. Tighten using the $\frac{1}{8}$ " **ALLEN WRENCH** (provided).

STEP FOUR

4. Tighten bottom mounting screw on the **L-BRACKET** WITH the $\frac{5}{32}$ " **ALLEN WRENCH** (provided).

K
KIRK enterprises

www.kirkphoto.com
800.626.5074 • 260.665.3670
333 Hoosier Drive, Angola, IN 46703-9336