

AC-3WT



*ActionCam*  
3-in-1  
Adjustable  
Arm

REVO<sup>TM</sup>

*Thank you for choosing Revo.*

The Revo 3-in-1 Adjustable Arm is designed to work as a selfie stick, camera grip, or tripod. Attach your GoPro unit, smartphone, or point-and-shoot camera with necessary adapter (available separately) and film your action as it happens. It is foldable to 7.5" (19 cm) for storage but can be extended up to 20" (51 cm) for extra reach when filming above a crowd or when you need a unique angle.

You can use it with the extension arms, configurable in multiple positions, or as a stand-alone action grip attached directly to your camera. Located in the action grip is a mini tripod. This can be attached to the base of the action grip or used with other adapters (available separately) to hold your point-and-shoot camera, GoPro unit, or smartphone when you want a steady aid to capture the activity. Made for action recording, the 3-in-1 Adjustable Arm is water proof and has two locking knobs to secure the extension arms in place as well as a safety thumb lock.

---

### *Specifications*

Dimensions (W × D × H):  
2.25" × 2" × 7.5" (5.7 × 5 × 19 cm)


Weight: 8 oz. (226 g)

Folded length: 7.5" (19 cm)

Extended length: 20" (51 cm)

Max load capacity: 1.1 lb. (500 g)


Components



*Note:* You will need an adapter to attach your GoPro, point-and-shoot camera, or smartphone to the Revo 3-in-1 Adjustable Arm. (Adapters are available separately.) We have included a thumbscrew to secure the adapters to the unit.

### *Using the 3-in-1 Adjustable Arm as a Selfie Stick*

1. Loosen the locking knobs on the action grip and extension arm before opening the unit.
2. Pull the extension arms out and upwards to the desired extended position.
3. Tighten both locking knobs after you have the extension arms at your preferred setting.
4. Attach your GoPro, point-and-shoot camera, or smartphone.



### *Closing the 3-in-1 Adjustable Arm*

1. Detach your GoPro, point-and-shoot camera, or smartphone from the extension arm.
2. Loosen the locking knobs on both the action grip and extension arms.
3. Retract the extension arms down to the action grip.
4. Press the safety thumb lock so that the extension arms fully collapse.
5. Tighten the locking knobs on both the action grip and extension arms.


### *Using Only the Action Grip*

1. Loosen the locking knob on the action grip and lift up on the extension arm until you hear a click.
2. Unscrew the locking knob fully to remove the extension arm.
3. Work the extension arm back and forth until you can remove it from the action grip.
4. Attach your GoPro, point-and-shoot camera, or smartphone directly to the action grip.

### *Using the Tripod with the Action Grip*


1. Loosen the action grip locking knob and swing out the extension arm until you hear a click.
2. Unscrew the tripod from the base of the action grip.
3. Turn the tripod around and screw it back into the base of the action grip with the tripod legs outward.
4. Fold out each of the tripod legs and place the unit in a stable-standing position.

**Note:** It is possible to use the tripod with the action grip and extension arms attached.




## *Using Only the Tripod*

1. Unscrew the tripod from the base of the action grip and remove its screw-top cap to reveal its adapter receiver.
2. Attach your GoPro, point-and-shoot camera, or smartphone directly to the tripod.




## *Using the Action Grip in the Follow Motion Position*

1. Loosen the locking knob on the action grip and swing the arm out 90°.
2. Tighten the action grip locking knob.
3. Loosen the locking knob on the extension arm and swing it a full 180° and then 90° to become parallel with the action grip.
4. Tighten the extension arm locking knob.
5. Attach your GoPro, point-and-shoot camera, or smartphone.



## Attaching the Wrist Strap

1. Thread the end of the strap through the strap hole, located at the base of the action grip.
2. Pull the other end of the strap through the loop of the threaded end.



---

## Precautions

- Please read and follow these instructions, and keep this manual in a safe place.
- Handle the unit with care.
- Clean the unit with a soft, dry cloth.
- Keep this unit away from children.
- Make sure everything is secure before proceeding.
- Make sure the item is intact and that there are no missing parts.
- Do not exceed the maximum load capacity.
- All photos are for illustrative purposes only.

## One-Year Limited Warranty

This Revo product is warranted to the original purchaser to be free from defects in materials and workmanship under normal consumer use for a period of one (1) year from the original purchase date or thirty (30) days after replacement, whichever occurs later. The warranty provider's responsibility with respect to this limited warranty shall be limited solely to repair or replacement, at the provider's discretion, of any product that fails during normal use of this product in its intended manner and in its intended environment. Inoperability of the product or part(s) shall be determined by the warranty provider. If the product has been discontinued, the warranty provider reserves the right to replace it with a model of equivalent quality and function.

This warranty does not cover damage or defect caused by misuse, neglect, accident, alteration, abuse, improper installation or maintenance. EXCEPT AS PROVIDED HEREIN, THE WARRANTY PROVIDER MAKES NEITHER ANY EXPRESS WARRANTIES NOR ANY IMPLIED WARRANTIES, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. This warranty provides you with specific legal rights, and you may also have additional rights that vary from state to state.

To obtain warranty coverage, contact the Revo Customer Service Department to obtain a return merchandise authorization ("RMA") number, and return the defective product to Revo along with the RMA number and proof of purchase. Shipment of the defective product is at the purchaser's own risk and expense.

For more information or to arrange service, visit [www.revocinegear.com](http://www.revocinegear.com) or call Customer Service at 212-594-2353.

Revo is a registered trademark of the Gradus Group.  
© 2015 Gradus Group LLC. All Rights Reserved.

Product warranty provided by the Gradus Group.  
[www.gradusgroup.com](http://www.gradusgroup.com)

