# Ruggard

## ICB-1517F Folding Padded Printer Carrying Case



## **User Manual**

The Ruggard ICB-1517F Folding Padded Printer Carrying Case is the perfect solution for safely hauling your printer to location shoots so you can print photos for your clients. The ICB-1517F incorporates a folding-panel design and is easy to unpack for one-time set up. Its interior panels are made from 3/4" thick foam padding over high-impact plastic honeycomb to protect your printer without unnecessary bulk and weight. The durable 600-denier ballistic nylon exterior resists minor scrapes and bad weather. Inside, the adjustable cushioned divider holds your printer in place and helps organize your gear. Three sturdy handles provide convenient carrying options, and zip pockets on the front of the case and under the lid offer additional storage for slim items.



- Please read and follow these instructions and keep this manual in a safe place.
- Keep this product away from water and any flammable gases or liquids.
- Handle this product with care.
- Clean this product with only a soft, dry cloth.
- Keep this product away from children.
- Use only parts provided by the manufacturer.
- Make sure that this product is intact and that there are no missing parts.
- All photos are for illustrative purposes only.

#### Specifications

- Interior dimensions (W × D × H): 17" × 15" × 12" (43.2 × 38.1 × 30.5 cm)
- Folded dimensions (W × D × H): 18.5" × 16.5" × 7" (47 × 41.9 × 17.8 cm)
- Weight: 6.8 lb. (3.1 kg)

### Contents Include:

- Outer shell
- L-shaped side panels (×2)
- Adjustable inner divider (×1)
- User manual

- 1. Unzip and unfold the case.
- 2. Align one of the included L-shaped side panels inside the case. There is one touch strip along the top outer edge of the panel and two touch strips on the interior of the long side. Make sure the long and short sides of the panels match up with the corresponding walls.
- 3. Fasten the touch strips along the top edge of the case. Make sure the side panel's touch tab is facing away from the wall.



- 4. Align the second L-shaped side panel with the case and insert it short-side first, under the first panel's touch tab.
- 5. Swing the long end of the panel toward the remaining interior wall so that all four walls of the case are supported by panels.





- 6. Fasten the side panels' touch tabs as well as the touch strips along the top edge of the case.
- 7. Insert the divider as desired and fasten the touch tabs to the side panels.



This Ruggard product is warranted to the original purchaser to be free from defects in materials and workmanship under normal consumer use for a period of one (1) year from the original purchase date or thirty (30) days after replacement, whichever occurs later. The warranty provider's responsibility with respect to this limited warranty shall be limited solely to repair or replacement, at the provider's discretion, of any product that fails during normal use of this product in its intended manner and in its intended environment. Inoperability of the product or part(s) shall be determined by the warranty provider. If the product has been discontinued, the warranty provider reserves the right to replace it with a model of equivalent quality and function.

This warranty does not cover damage or defect caused by misuse, neglect, accident, alteration, abuse, improper installation or maintenance. EXCEPT AS PROVIDED HEREIN, THE WARRANTY PROVIDER MAKES NEITHER ANY EXPRESS WARRANTIES NOR ANY IMPLIED WARRANTIES, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. This warranty provides you with specific legal rights, and you may also have additional rights that vary from state to state.

To obtain warranty coverage, contact the Ruggard Customer Service Department to obtain a return merchandise authorization ("RMA") number, and return the defective product to Ruggard along with the RMA number and proof of purchase. Shipment of the defective product is at the purchaser's own risk and expense.

For more information or to arrange service, visit www.ruggard.com or call Customer Service at 212-594-2353.

Product warranty is provided by the Gradus Group. www.gradusgroup.com

Ruggard is a registered trademark of the Gradus Group. © 2015 Gradus Group LLC. All Rights Reserved.



GG1



© Copyright 2015 Gradus Group www.ruggard.com