1/4"-20 Threaded Screw

Your PRO 423PX comes with a 1/4"-20 threaded screw at the top of the Center Column. It also comes with a 3/8" screw adapter located in the base of the Pistol Grip Ball Head. To use it as a 3/8" center column, remove the Pistol Grip head, unscrew the adapter and screw it on the top of the Center Column.



Short Center Column

Your Sunpak PRO 423PX tripod also comes with a Short Center Column for low angle use. To remove the standard Center Column, first loosen the Center Column Lock Knob and simply unscrew the accessory hook plate from the bottom of the Center Column, and remove it from the tripod body. Then install the Short Center Column for use.



Precautions

- Insure that all handles, knobs and leg locks are properly tightened, and that all three legs are fully angled opened before use.
- Do not carry or transport the tripod with the camera equipment attached (as example but not limited to: over your shoulder or cradled in your arms).
- Do not Oil or Grease any part of the tripod.
- Do not use any solvents or thinners to clean your tripod. Use mild detergent and wipe dry with a soft, lint-free cloth only.
- Do not store or expose your tripod to excessive heat or cold or use close to any flame or fire.
- Do not exceed the load limit for this product.

SUNPAK LIMITED LIFETIME WARRANTY

This SUNPAK product has been carefully manufactured, accurately adjusted, inspected and thoroughly tested before shipment to assure you of the highest quality.

Should this SUNPAK product require service, we will repair or replace, at our option, any part or the product itself, which our examination shows to be defective in material or workmanship. This warranty does not apply to wear and tear associated with the normal use of the product. This warranty is non-transferable.

Repairs will be made to the product at no charge, under the terms of the warranty as stated above, only when accompanied by a dated and itemized bill of sale and nominal handling charge.

Be certain to follow all assembly and/or operating instructions with this product. This warranty is not valid if the product has been misused or damaged in any way that is beyond our control or through normal wear and tear associated with use. This warranty applies only to the product and we are not responsible in any way for losses, damages or any inconvenience caused by equipment failure.

Some states do not allow the exclusion or limitation of consequential damages, so the above limitation or exclusion may not apply to you. This warranty gives you specific legal rights and you may have other rights which may vary from state to state.

Should service be required, the product should be carefully packed (in the original packaging if possible) and sent, prepaid and insured, along with a check or money order for \$15.95 (shipping and handling), to the address listed below. A note briefly describing the nature of the defect should also be enclosed to expedite handling.

Proof of purchase and payment for shipping and handling

OWNER'S RECORD

Please c	omplete this	section	and	retain	with	your	original	bill	of
		sale for	your	record	ds.				

D. D. 4.

Purchase Date	
State	Zip Code

ToCAD America Inc.

Sunpak Tripod Division 53 Green Pond Road Rockaway, NJ 07866 973-627-9600 tocad.com

SUNPAK® PRO 423PX

Operating Instructions

Congratulations on the purchase of your new SUNPAK tripod. Your tripod has been designed to be a sturdy, rugged, and dependable product and will provide you with many years of reliable service.

Please spend a few moments reviewing these instructions, so that you can take full advantage of your tripod's features and capabilities.



Cat. no. 620-423-CFT-PX2

PRO 423PX2 Specifications

3 Leg Sections Leg Construction Carbon Fiber Maximum Height 66.75 in. Minimum Height 10.5 in. Folded Length 26.5 in. Leg Diameter .75 in. Weight 3 lbs. Load Capacity 15.4 lbs.

Tripod Components (See Picture Below)

- 1. Pistol Grip Ball Head with Quick Release
- 2. Trigger Control Lock
- 3. Quick Release Plate
- Quick Release Lock Lever with Locking Mechanism
- 5. Center Column Lock Knob
- Leg Angle Adjustment Latch
- 7. Center Column
- 8. Retractable Accessory Hook
- 9. Flip Lock Leg Locks
- Rubber Feet with Retractable Leg Spikes
- 11. Short Center Column



Extending the Legs

Each leg of the PRO 423PX has separate leg extensions and each segment may be withdrawn as needed by using the flip lock leg locks. This permits setting your equipment at a comfortable height can be very useful when positioning your tripod on uneven terrain. To secure, close the lea lock firmly in place. Not properly securing a leg lock may cause the tripod leg to retract and may cause damage to your tripod and camera.

Adjusting Leg Angle

To change the operation angle of any leg, fold the leg in slightly towards the center column, push downward on the Leg Angle Adjustment Latch until it locks. You can then spread the leg outward to it lowest angle, or fold the legs inward, which will lock the legs at greater angles, if desired.



Using the Pistol Grip Ball Head

For movement in any direction, simply loosen the Pistol Grip Ball Head, by squeezing the Trigger Control Lock. When you have reached your desired position, simply release the trigger lock and the Pistol Grip Ball Head will lock into place. The Pistol Grip Ball Head can rotate to 360° in any direction.



Quick Release Plate

Push forward the Locking Mechanism located just below the Quick Release Lock Lever. Move the Quick Release Lock Lever outward and remove the Quick Release Plate by lifting upward. The platform has a threaded ½ x 20 camera mounting screw for camera attachment.

Position the Quick Release Plate so that the camera mounting screw aligns with the matching receptacle on your camera or camcorder and attach, using the camera mounting screw. Move and hold open the Quick Release Lock Lever and with the camera tilted slightly down, slide the Quick Release Plate back into position. After doing so, secure the Quick Release Plate using the Quick Release Lock Lever by pressing firmly until it stops. Note: Do not attempt to open the Quick Release Lock Lever without pressing the Locking Mechanism first.



Height Adjustments

Your Sunpak PRO 423PX tripod is equipped with a Lift-n-Lock Center Column for precise height adjustments.

To raise or lower the Center Column, loosen the Center Column Lock Knob. Grasp the tripod head and lift to the desired height. Retighten the Center Column Lock Knob to secure.

Note: Never release your camera until the Center Column Lock Knob is securely retightened.

