

Product Description: Shoulder Harness V2.0

Converts a Shoulder Bag Into a Backpack

For more information please visit: www.thinktankphoto.com

thinkTANK® photo
Be Ready "Before The Moment"™



Product Description:

Travel smarter and don't wrestle with a swinging shoulder bag. The Shoulder Harness V2.0 conveniently carries a shoulder bag like a backpack. This balances the bag's weight over two shoulders instead of only one shoulder. Photographers can be more comfortable during long distance travels by using this accessory strap. New features include an adjustable sternum strap, webbing loops for Camera Support Strap attachment (support straps sold separately), and a flap that conceals the rear attachment buckle. Shoulder Harness V2.0 attaches quickly and easily folds for storage, when not in use.

Key Features:

- Sternum strap across shoulder straps stabilizes load
- Webbing loops for attaching Camera Support Straps (sold separately)
- D-rings on front for small accessories
- Flap over rear attachment buckle conceals connection point
- Compatible with Urban Disguise 30, 35, 40, 50, 60, and 70 Pro
- Easily compressed for travel
- Fully adjustable, one size fits most
- Made of durable ripstop nylon
- "No Rhetoric" lifetime warranty

Specifications:

SKU: 87453000 582 4 • Part Number: 582

- One size fits all
- WEIGHT: 8.5 oz (241 g)



The rear attachment of Shoulder Harness V2.0 wraps around the shoulder bag handle(s) to support the bag's weight. Fully open the attachment and set the handles between the buckle ends.



Clip the buckle together over the handles. Then cover the buckle with the concealment flap and seal the hook-and-loop underneath and behind the assembly.



Connect the front ends of the shoulder straps to the D-rings at the bottom corners of the shoulder bag. Finally, adjust the shoulder straps and sternum strap up or down for a proper fit.