

## WARRANTY REGISTRATION

**Visit [www.ultimatesupport.com](http://www.ultimatesupport.com)** for a quick and convenient process for registering your new Ultimate Support product. Warranty Registration and Proof of Purchase are required for warranty fulfillment. Full Limited Lifetime Warranty and Ultimate Protection Plus Premium Service and Support Plan details are available online under Music Gear & Instrument Stands / Customer Support.

**ULTIMATE**  
S U P P O R T

### LIMITED LIFETIME WARRANTY

Ultimate Support products are constructed of the finest materials and designed and tested to stand up to the demanding lifestyle of the touring musician, gigging DJ, and working sound engineer. In the unlikely event that a product should fail due to manufacturing defect, Ultimate Support is pleased to repair or replace that product.

**Please see [www.ultimatesupport.com](http://www.ultimatesupport.com) for more information.**

This warranty applies to the original purchaser only and does not include damage to the product resulting from normal wear and tear, accident, misuse, improper installation or operation, or unauthorized repair or alterations.

800.525.5628 . [www.ultimatesupport.com](http://www.ultimatesupport.com) . Copyright 2012, Ultimate Support Systems . All Rights Reserved

**ULTIMATE**  
S U P P O R T

THE STRENGTH OF INNOVATION®



Product Manual  
for Ultimate Support  
**V-STAND® PRO**

**VS-88B**  
ITEM #17479

**ULTIMATE**  
S U P P O R T  
LIMITED LIFETIME WARRANTY

Revision 7, 09.15.12 . Product Manual Item #Manual\_17479M

## V-STAND® PRO SETUP INSTRUCTIONS

STEP 1



1. Lay stand on floor in folded position.

STEP 2



2. Separate both legs outward until they stop.

STEP 3



3. Secure legs in open position with locking pins.

STEP 4



4. Pull vertical struts upward to a vertical position and spread them to their open position.

STEP 5



5. Move support arms into their horizontal position by swinging them up and over the vertical struts.

STEP 6



6. Secure arms in horizontal position with locking pins.

## HEIGHT ADJUSTMENT



For safety's sake, be sure to adjust V-Stand® Pro height **ONLY** when keyboard is not on stand.

STEP 1



1. Pull, or rotate, locking pin collar out to release inner strut.

STEP 2



2. Raise or lower inner strut to desired height and push, or rotate, locking pin collar into locking position.

STEP 3



3. Repeat steps 1-2 on opposite inner strut. NOTE: Make sure height settings match on both inner struts before placing keyboard on V-Stand® Pro!