

AUTO LENS ADAPTER

USER MANUAL

LAE-MFT-FT

Four Thirds Lens to Micro Four Thirds Camera



INTRODUCTION

Thank you for purchasing the Vello LAE-MFT-FT Auto Lens Adapter - Four Thirds Lens to Micro Four Thirds Camera. This adapter allows you to mount a Four Thirds lens to any Panasonic or Olympus Micro Four Thirds camera. With a compatible lens mounted to a Micro Four Thirds camera using this adapter, all automatic functions, such as auto focus and auto exposure, are available and fully operational.



OVERVIEW

The Vello Auto Four Thirds Lens Adapter can expand the arsenal of lenses for your Micro Four Thirds camera at very low cost. With this adapter, you can mount any Four Thirds lenses you have to any Panasonic or Olympus Micro Four Thirds camera. Just attach the adapter to your Four Thirds lens, then mount the lens and adapter to your Micro Four Thirds camera. All camera functions will operate normally, including auto focus, auto exposure, and touch-screen modes.

PRECAUTIONS

- Do not use this adapter in combination with any other Four Thirds system accessory, such as a tele-converter or an extension tube.
- Mount the lens to the adapter in a dust-free environment.
- Avoid sandy or dusty environments when using this adapter.
- Handle the adapter with care—don't drop it, and avoid bumps and shocks.
- Clean the adapter by wiping it with a soft, dry cloth.
- Do not use solvents such as benzene, alcohol, detergents, etc. to clean the adapter.
- Be sure to read the operating instructions for your digital camera.

- Keep this unit away from water and flammable gases or liquids.
- Do not attempt to disassemble or repair the equipment—doing so will void the warranty, and Vello will not be responsible for any damage.
- Handle the unit with care.
- Keep this unit away from children.
- Use only parts provided by the manufacturer.
- All photos are for illustrative purposes only.
- Please read and follow these instructions, and keep this manual in a safe place.

CONTENTS INCLUDE

- Vello LAE-MFT-FT Auto Lens Adapter - Four Thirds Lens to Micro Four Thirds Camera
- Front and rear caps
- User manual

SPECIFICATIONS

- Dimensions – 2.6" diameter × 0.8" length (65 × 19.5 mm)
- Weight – 2.9 oz. (83 g)



ATTACHING THE MOUNT ADAPTER

1. Close the camera's flash.
2. Turn the camera's power off.
3. Remove the rear lens cap, camera body cap, and mount adapter caps.
4. Align the inner red dot on the lens adapter with the red dot on the lens.



5. Slowly and carefully insert the lens into the adapter and carefully rotate it clockwise until it clicks into place.



6. Align the red mark on the lens adapter with the red lens attachment mark on the camera and slowly rotate the adapter and lens clockwise until it clicks into place on the camera.



REMOVING THE MOUNT ADAPTER

1. Close the camera's flash.
2. Turn the camera's power off.
3. Hold down the lens release button on the camera and rotate the lens and adapter counterclockwise until they come to a stop. Remove from the camera.



4. Hold down the release button on the adapter mount, and remove the lens by rotating it counterclockwise until it comes to a stop.
5. Separate the lens from the adapter mount.
6. Replace the rear lens cap, camera body cap, and mount adapter caps.



One-Year Limited Warranty

Vello provides a limited warranty to the original purchaser that this product is free from defects in materials and workmanship under normal consumer use for a period of one (1) year from the original purchase date or thirty (30) days after replacement, whichever occurs later. Vello's responsibility with respect to this limited warranty shall be limited solely to repair or replacement, at Vello's discretion, of any product that fails during normal consumer use. Inoperability of the product or part(s) shall be determined by Vello. If the product has been discontinued, we reserve the right to replace it with a model of equivalent quality and function. To obtain warranty coverage, contact Vello to obtain a return merchandise authorization ("RMA") number, and return the defective product to Vello, along with the RMA number and proof of purchase. Shipment of the defective product is at the purchaser's own risk.

This warranty does not cover damage or defect caused by misuse, neglect, accident, alteration, abuse, improper installation or maintenance. EXCEPT AS PROVIDED HEREIN, VELLO MAKES NEITHER ANY EXPRESS WARRANTIES NOR ANY IMPLIED WARRANTIES, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. This warranty provides you with specific legal rights, and you may also have additional rights that vary from state to state.



www.vellogear.com

© Copyright 2013 Gradus Group