



**EPN-DK19**  
RUBBER EYEPIECE  
FOR SELECT NIKON  
CAMERAS



USER'S MANUAL

## INTRODUCTION

### **Thank you for choosing Vello.**

The Vello EPN-DK19 Rubber Eyepiece for Select Nikon Cameras improves comfort over the standard eyepiece and prevents stray light from entering the viewfinder, making the eyepiece especially useful while working outdoors in bright sunlight. The eyecup mounts securely to the camera, and the soft and durable rubber construction prevents scratches to eyeglasses.

## PRECAUTIONS

- Please read and follow these instructions and keep this manual in a safe place.
- Keep this product away from children.
- To avoid damage to this product, be careful not to overtighten or improperly thread the threaded fitting.
- All photos are for illustrative purposes only.

## CONTENTS INCLUDE

- EPN-DK19 Rubber Eyepiece
- Metal retainer ring
- User manual

## INSTRUCTIONS

1. Close your camera's eyepiece shutter to unlock the eyepiece, and unscrew the eyepiece to remove.



2. Remove the rubber ring from around the camera's eyepiece.



**3. Remove the metal retainer ring from the Vello eyecup.**



**4. With the ridges up, insert the camera's eyepiece into the top of the Vello eyecup. Make sure the eyepiece is fully inserted, and not resting on top of the eyecup.**



5. Replace the metal retainer ring around the top of the eyecup. Wipe off any fingerprints from the eyepiece.



6. Mount the eyecup assembly onto the camera by screwing it into the viewfinder. When the assembly is fully screwed on, open the eyepiece shutter to lock the eyepiece.



# ONE-YEAR LIMITED WARRANTY

This VELLO product is warranted to the original purchaser to be free from defects in materials and workmanship under normal consumer use for a period of one (1) year from the original purchase date or thirty (30) days after replacement, whichever occurs later. The warranty provider's responsibility with respect to this limited warranty shall be limited solely to repair or replacement, at the provider's discretion, of any product that fails during normal use of this product in its intended manner and in its intended environment. Inoperability of the product or part(s) shall be determined by the warranty provider. If the product has been discontinued, the warranty provider reserves the right to replace it with a model of equivalent quality and function.

This warranty does not cover damage or defect caused by misuse, neglect, accident, alteration, abuse, improper installation or maintenance. EXCEPT AS PROVIDED HEREIN, THE WARRANTY PROVIDER MAKES NEITHER ANY EXPRESS WARRANTIES NOR ANY IMPLIED WARRANTIES, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. This warranty provides you with specific legal rights, and you may also have additional rights that vary from state to state.

To obtain warranty coverage, contact the Vello Customer Service Department to obtain a return merchandise authorization ("RMA") number, and return the defective product to Vello along with the RMA number and proof of purchase. Shipment of the defective product is at the purchaser's own risk and expense.

For more information or to arrange service, visit [www.vellogear.com](http://www.vellogear.com) or call Customer Service at 212-594-2353.

Product warranty provided by the Gradus Group.  
[www.gradusgroup.com](http://www.gradusgroup.com)

VELLO is a registered trademark of the Gradus Group.  
© 2015 Gradus Group LLC. All Rights Reserved.



[www.vellogear.com](http://www.vellogear.com)

