LENS ADAPTER MANUAL

LA-CEF-LR LA-MFT-LR





INTRODUCTION

Thank you for choosing a Vello Lens Adapter. Vello lens adapters allow you to use lenses from manufacturers other than the maker of your camera body, so you can mount a lens on a camera body with which it would otherwise be incompatible. Vello Lens Adapters fit securely to the lens, but not so tightly that they are difficult to remove. Please follow these instructions to mount and remove your Vello Lens Adapter.

Although the lens will fit physically, automatic diaphragm (AE metering), and other functions dependent on communication between the camera body and lens, will be disrupted by a lens adapter. You will need to set exposures manually or meter in aperture priority (stop-down) mode. Focusing to infinity is retained.

All images are for illustrative purposes only.

TO MOUNT THE LENS ADAPTER

Note: Place the lens on a stable, flat surface when mounting or removing your Vello Lens Adapter.



I. Line up the release tab on the lens adapter with the red alignment dot on the lens.



2. Rotate the lens adapter clockwise until it locks into place.



3. Line up the alignment dots on the lens adapter and the camera.



4. Rotate the lens assembly clockwise until it locks into place.

TO REMOVE THE LENS ADAPTER



Press the lens release button on the camera.



2. Rotate the lens assembly counterclockwise to release.



3. Lift and hold the release tab on the lens adapter.



4. Rotate the lens adapter counterclockwise to release.

For Micro Four-Thirds (MFT) cameras, enable the "Shoot without Lens" function in the menu of the camera.

ONE-YEAR LIMITED WARRANTY

This VELLO product is warranted to the original purchaser to be free from defects in materials and workmanship under normal consumer use for a period of one (1) year from the original purchase date or thirty (30) days after replacement, whichever occurs later. The warranty provider's responsibility with respect to this limited warranty shall be limited solely to repair or replacement, at the provider's discretion, of any product that fails during normal use of this product in its intended manner and in its intended environment. Inoperability of the product or part(s) shall be determined by the warranty provider. If the product has been discontinued, the warranty provider reserves the right to replace it with a model of equivalent quality and function.

This warranty does not cover damage or defect caused by misuse, neglect, accident, alteration, abuse, improper installation or maintenance, EXCEPT AS PROVIDED HEREIN, THE WARRANTY PROVIDER MAKES NEITHER ANY EXPRESS WARRANTIES NOR ANY IMPLIED WARRANTIES, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTIES TO ANY EXPRESS FOR A PARTICULAR PURPOSE. This warrant, provider you with specific legal cipits that the particular purpose and you may also have additional cipits that your form state to a trate.

To obtain warranty coverage, contact the Vello Customer Service Department to obtain a return merchandiss authorization ("RMA") number, and return the defective product to Vello along with the RMA number and proo of purchases. Shipment of the defective product is at the purchaser's own risk and expense.

For more information or to arrange service, visit www.vellogear.com or call Customer Service at 212-594-235.

Product warranty provided by the Gradus Group.

www.gradusgroup.com

VELLO is a registered trademark of the Gradus Group
© 2014 Gradus Group LLC. All Rights Reserved





www.vellogear.com

© Copyright 2014 Gradus Group

Vello and other names of Vello products are trademarks of Gradus Group. Other product and corporate names mentioned herein are trademarks of their respective holders.