

# QUICKDRAW

## ROTATING FLASH BRACKET

Thank you for choosing the Vello QuickDraw Bracket. The QuickDraw puts you in control of your lighting whether you're shooting horizontally or vertically, and allows you to switch between the two orientations with just a quick flip of the rotating arm.

Please follow the instructions below to get the most out of your QuickDraw Bracket and to prevent improper installation which may cause damage to your equipment.



### MOUNTING THE CAMERA

There are five mounting holes on the bracket's camera platform. Place your camera on the platform and align your camera's mounting socket with the mounting hole that best centers your camera on the bracket. Attach the camera to the QuickDraw bracket using the 1/4"-20 mounting knob. Tighten the knob until firmly connected.


### MOUNTING THE FLASH

The QuickDraw Bracket is equipped with an accessory-shoe mount which can be used to mount your flash unit or TTL cord. To mount your flash, loosen the red knob on the cold-shoe, insert your flash, and tighten the knob. Unless you are using a wireless flash system, you will need to connect your flash to the camera with the appropriate cord. You may use cable ties or an optional cord wrap to secure the cord alongside the bracket.

To attach separate flash heads such as Norman or Lumedyne, or the Nikon SC-28 and SC-29 off-camera shoe cords, remove the cold shoe mount from the flash arm and use the included mounting screw to mount the flash head to the bracket.


### USING THE BRACKET FOR HORIZONTAL SHOOTING

Position the flash arm so that it is raised directly above the top of the camera's body with the flash mount centered above the lens when the camera is held horizontally.



### USING THE BRACKET FOR VERTICAL SHOOTING

Rotate the flash arm 180° to center the flash above your lens when the camera is held vertically.



### Limited Five-Year Warranty

Vello provides a limited warranty that this product is free from defects in materials and workmanship to the original purchase under normal use for a period of five (5) years from the original purchase date. Vello's responsibility with respect to this limited warranty shall be limited solely to repair or replacement, at its option, of any product which fails during normal consumer use. This warranty does not extend to damage or failure which results from misuse, neglect, accident, alteration, abuse, improper installation or maintenance. EXCEPT AS PROVIDED HEREIN, VELLO MAKES NEITHER ANY EXPRESS WARRANTIES, NOR ANY IMPLIED WARRANTIES, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. To obtain a replacement during the time of this warranty, please return the defective item with proof of purchase, along with an RMA number to the place of purchase. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.