

IP-KC01



Bluetooth Keyboard Case

For iPhone 5

User Manual



XUMAI™

Thank you for choosing Xuma.




The Xuma IP-KC01 Bluetooth Keyboard Case features a Bluetooth keyboard with a magnetized surface that attaches to the included hard-shell iPhone 5 case. The case mounts to the keyboard in portrait or landscape orientation, and the keyboard conveniently stores under the case when not in use. The keyboard recharges via a USB charging plate. It boasts an ultraslim design and three shortcut keys for optimal functionality.



Here are the basic instructions to guide you through the setup and synchronization process.

Product Overview



Specifications

Bluetooth Keyboard Case Specifications	
Bluetooth interface	Standard 3.0
Operating distance	Up to 33 ft. (10 m)
Standby time	160 hr.
Charging time	1 hr.
Battery capacity	40 mAh
Uninterrupted working time	38 hr.
Operating temperature	14°F to 131°F (-10°C to 55°C)

Box Contents

1. iPhone Case
2. Bluetooth Keyboard
3. Charging Plate
4. USB Cable
5. User instruction manual (this booklet)



The wireless keyboard can connect to iPhone models 3G, 3GS, 4, 4S, and 5, and iPod Touch models running iOS 4.0 or later

Keyboard

Dimensions	5 × 2.4 × 0.1 in. (12.7 × 6.2 × 0.25 cm)
Weight	1.5 oz. (43 g)

Phone Case

Dimensions	5 × 2.4 × 0.07 in. (12.7 × 6.2 × 0.178 cm)
Weight	0.9 oz. (26 g)

Precautions

1. Please read and follow these instructions and keep this manual in a safe place.
2. Keep this product away from water and all flammable gases or liquids.
3. Do not attempt to disassemble or repair this product.
4. Clean this product with only a soft, dry cloth.
5. All photos are for illustrative purposes only.

Charging

1. Use the included USB charging cable to connect the charging plate to a USB power source (not included). The charging LED will glow when the plate is connected to a power source.
2. Match up the charging contacts on the rear of the keyboard with the charging plate, and place the keyboard inside the plate. The CHARGE LED on the keyboard will glow when the unit is charging, and will turn off when charging is complete.



When battery power is low, the CHARGE LED on the keyboard will blink.

Getting Started

1. Insert your iPhone into the case so your iPhone's external controls fit into the corresponding openings in the case.
2. Push down on the other side of the iPhone so it locks into the case.

The keyboard and the case attach via their magnetic surfaces, and can be used in landscape and portrait orientations. For landscape orientation, make sure the camera openings on the case and the keyboard are aligned (Figure 1).

For portrait orientation, align the bottom of the case with the dotted line on the keyboard's magnetic surface (Figure 2).




Figure 1



Figure 2

Pairing Up the Keyboard

1. Turn on the keyboard by pressing and holding the power switch until the Bluetooth light glows. It will glow, turn off, and then blink rapidly until paired.
2. On your iPhone, select Settings → Bluetooth (Figure 3).
3. Select ON to activate the iPhone's Bluetooth feature. The iPhone will automatically search for available Bluetooth devices.
4. Select "Bluetooth keyboard for iPhone 5" from the list of discovered Bluetooth devices (Figure 4).



Figure 3




Figure 4



After the initial setup is complete, your iPhone will automatically recognize your Xuma keyboard for future use.

Turning off the keyboard, Reconnecting, and Sleep Mode

To turn off the keyboard, press and hold the power key until the Bluetooth LED blinks. The keyboard will turn off and disconnect from your iPhone.

To reconnect the keyboard, press and hold the power key until the Bluetooth LED glows. The keyboard will turn on and reconnect with your iPhone.

When the keyboard is inactive for several minutes, it will enter sleep mode in order to conserve battery power. Press any key to wake up the keyboard.

Shortcut Keys

The shortcut keys are shortcuts to various functions on your iPhone. They are located in the top row, on the 5, 6, and 7 keys. Press Fn + the key to access the shortcut.



Home



Onscreen keyboard



International keyboard

Troubleshooting

Following are a few common problems that may arise during the operation of your Bluetooth Keyboard Case, and basic troubleshooting solutions to avoid them.

Problem	Solution
The keyboard does not respond.	Make sure that the wireless keyboard is turned on and paired up, and that the battery is charged.
The wireless keyboard is not pairing up with the iPhone.	<p>Make sure that the wireless keyboard and the iPhone are turned on, and that their batteries are charged.</p> <p>Make sure the wireless keyboard is within operating distance of the iPhone (33 feet or 10 meters).</p> <p>Make sure the iPhone's Bluetooth setting is turned on.</p> <p>Make sure to select Bluetooth Keyboard for iPhone 5 on the iPhone's list of discovered Bluetooth devices.</p>

Problem	Solution
The keyboard will not charge.	<p>Make sure the charging contacts on the keyboard and the charging plate are aligned.</p> <p>Make sure the USB cable is properly connected to the charging plate and the power source.</p> <p>If you are using a USB AC adapter (not included), make sure that it has an output of at least one ampere-hour (1Ah), and that it is properly plugged into the power outlet.</p>

ONE-YEAR LIMITED WARRANTY

Xuma provides a limited warranty to the original purchaser that this product is free from defects in materials and workmanship under normal consumer use for a period of one (1) year from the original purchase date or thirty (30) days after replacement, whichever occurs later. Xuma's responsibility with respect to this limited warranty shall be limited solely to repair or replacement, at Xuma's discretion, of any product that fails during normal consumer use. Inoperability of the product or part(s) shall be determined by Xuma. If the product has been discontinued, we reserve the right to replace it with a model of equivalent quality and function.

To obtain warranty coverage, contact Xuma to obtain a return merchandise authorization ("RMA") number, and return the defective product to Xuma, along with the RMA number and proof of purchase. Shipment of the defective product is at the purchaser's own risk.

This warranty does not cover damage or defect caused by misuse, neglect, accident, alteration, abuse, improper installation or maintenance. EXCEPT AS PROVIDED HEREIN, XUMA MAKES NEITHER ANY EXPRESS WARRANTIES NOR ANY IMPLIED WARRANTIES, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. This warranty provides you with specific legal rights, and you may also have additional rights that vary from state to state.



