


# Omicron3 Flash/Video Ring Light – OM3



# Flash / Video Operation

- •TTL or Manual flash controlled by CoPilot
- Video light for cameras with video capture

!! WARNING -- DANGEROUS HIGH VOLTAGE !!
The Omicron Flash/Video Ring light contains dangerous high voltages within. For professional use only. Do not disassemble this equipment. In the event of physical damage immediately disconnect power and return the unit to Quantum for repair.

## 1.0 Introduction

Omicron3 Flash/Video Ring Light provides both flash and continuous video lighting for ideal illumination. Designed specifically for 35mm SLR type still and video cameras, it is also adaptable to other camera types.

Omicron3's "chromatically correct" light spectrum emanates from 80 critically color-balanced LEDs. Colored LEDs mixed with white LEDs fill in the spectral gaps characteristic of white-only LED lights.

Omicron3 interfaces with Quantum CoPliot full coordination with Nikon or Canon camera systems, in TTL or manual modes.

Important : The firmware updates below may be required for Flash / Video Simultaneous Operation:

#### CoPilot:

### Canon cameras

CoPilot QF91C Version 1.06 or later, no update required.

### Nikon cameras

CoPilot QF91N Version 1.06 or later, no update required.

Visit <a href="www.qtm.com">www.qtm.com</a> to download the latest CoPilot firmware and click Support, Updates and Conversions

# 2.0 Overview

The Quantum Omicron 3 (OM3) Flash/Video Ring Light for flash/video operation consists of:

- OM3 Ring Light with removable lens for holding color gels
- CQ2 Flash cable for connecting OM3 to Quantum Turbo battery pack.
  OM3 can be powered by all Quantum Turbo batteries.

CQ8, CCQ8 cables may also be used with OM3

FW20 - Sync Cord manual flash trigger from camera.

FW31 - Din cable for connecting to Quantum CoPilot QF91 for TTL/Man Operation.

# 2.1 Additional Accessories

Qf91N - For TTL control of Omicron by Nikon cameras.

Qf91C - For TTL control of Omicron by Canon cameras.

QF51 – 20 ft. extension cable.

Extension cable connects the CoPilot to the OM3 for off camera TTL lighting.

### 434 / 435 Sync Cords


The CoPIlot has an internal radio that is compatible with the Quantum FreeXWire radio system.

To use another radio system connect the 434/435 sync cords to the camera PC, or use a hot shoe adapter from your camera manufacturer that includes a PC nipple.

# 3.0 Mounting & Power Accessories

## 3.1 Mounting

QF29 - for under camera mounting




OM42 - for twin rail mounting



**3.2 Power**Any TURBO battery

## 4.0 Flash operation

### 4.1 Connections




The "ON" indicator on OM3 should blink once per second. The OM3 is ready to operate.

If the "ON" indicator blinks three times per second, it indicates the High Voltage is not available. Check the Turbo battery pack operation.

#### 4.2 Flash Modes

Two modes of flash operation are available, TTL and manual. Flash output can be adjusted in both modes using the Local switch located on top of the CoPilot.

Choose AF for
Auto Focus assist.
The OM3 will turn on in video mode during low light situations when the camera requires assistance in focusing.



## **Exposure Adjustment**

TTE

The exposure can be adjusted from -2<sup>7</sup> stops to +2 stops.

## Manual


Exposure can be adjusted from 1/32+ of the shutter speed to 1/1(full shutter speed).

When the CoPilot is set to - Manual mode, exposure is determined using the shutter speed.

When the CoPilot is set to TTL mode, the camera uses its' own internal metering system to determine the proper exposure.

# 5.0 Video Operation


### **5.1 Connections**



The "ON" indicator on OM3 should blink once per second. The OM3 is ready to operate.

If the "ON" indicator blink sthree times per second, it indicates the High Voltage is not available. Check the Turbo battery pack operation.

### 5.2 Video ON / OFF



Adjust the light intensity
Turn the intensity knob
clockwise to increase the
light intensity, countclockwise to decrease the
light intensity.


Press and hold the push button for 2 seconds. The **ON** light will turn off and the OM3 light will gradually dim.

### 5.3 Automatic Lighting Track (ALT) Operation

Automatic Lighting Track (ALT) Operation will keep the illumination on the subject constant when the distance between the subject and OM3 Ring Light changes. It will automatically decrease the light output level when the OM3 Ring Light is close to the subject. It will automatically increase the light output level when moving the OM3 Ring Light away from the subject.

#### **Turn OM3 ON**

Press the push button once and the  ${\bf ON}$  light will stay on steady. Aim the OM3 at your subject.



### Set light output level

Stand at the maximum distance you intend to shoot at and set the intensity knob to 100%. Your minimum shooting distance will be one half of your maximum.

### **Turn ON ATL**

While aiming at your subject, push the power button once. The "AUTO" indicator lights.

### Turn OFF the ATL

Push the push button once or adjust the light intensity knob, the "AUTO" indicator will turn off and "ON" indicator is on.

#### Indications

If the "AUTO" indicator is blinking fast, you are too lose to your subject and you need to move away.

If the "AUTO" indicator is blinking slowly, you are too far from your subject and you need to move closer.

# **6.0 Customer service**

Having any trouble I using your Quantum product? We are here to help. Mail, call, fax, or email our Service Department:

Service department Quantum Instruments 10 Commerce Drive Hauppauge, NY 11788

Tel: (631) 656-7400 Fax: (631) 656-7410 Website: www.gtm.com

Troubleshooting tips are available at www.qtm.com, Support, Customer Support, FAQ. If you suspect a malfunction or require adjustment, return the unit to us with an accurate description of the problem. Please be sure your problem is not caused by improper operating procedure or malfunctions in your other equipment. Send all equipment carefully packaged and insured to our address above.

An estimate of repair cost on out-of-warranty merchandise may be forwarded if you desire.

Normal repair time is 10 - 15 days. Paying by check will delay the repair until the check clears (up to 15 days). For expedited service, contact our Service Department.

#### Summary:

- Ship via UPS, Parcel Post, or other carrier, insured.
- Give a clear, detailed description of the problem.
- Give your mailing address and daytime phone number, fax #, and/or email.
- For warranty repairs include a copy of the receipt.

**Note:** Please do not e-mail your credit card information.

## **Limited Warranty**

Quantum products have a 1 year limited warranty. Please refer to the Limited Warranty card for complete details, conditions, and terms.



Quantum Instruments Inc.
10 Commerce Drive, Hauppauge NY 11788-3968 USA
Tel: 1-631-656-7400 Fax: 1-631-656-7410
www.qtm.com