

# WIRELESS PRESENTER

## User Manual



Thank you for choosing Xcellon.

The Xcellon Wireless Presenter is designed for anyone seeking the flexibility of controlling a presentation unencumbered by wires or having to hover over a computer. The hand-held device is compact, comfortable, and easy to use. Presenters can move freely and control the show smoothly from anywhere in the room. It includes a powerful laser pointer that enables the user to emphasize content and direct the audience to specific areas of a slide.


# Overview


---

1. Laser emitter
2. Power LED
  - When the Presenter is operational, the Power LED will glow whenever a button is pressed.
3. Next slide button
  - Press to advance one slide.
4. Laser button
  - Press to activate the laser pointer.
5. Previous slide button
  - Press to go back one slide.
6. Play/Escape button
  - Press to turn your presentation full screen. Press again to exit full screen.
7. Screen black button
  - Press to black the screen of your presentation.
8. Battery compartment cover
9. Stowed USB receiver

Also included:

- [USB receiver](#)
- Carrying case
- Two AAA batteries
- User manual





# Operation

## Installing Batteries

1. Locate the battery compartment on the back of the Presenter.
2. Slide open and remove the battery compartment door.
3. Remove old batteries if present.
4. Insert two fresh AAA batteries in the orientation indicated by the illustration within the compartment.
5. Slide the battery compartment door back into place to close it. You may hear a slight click, indicating the door has been securely closed.



When replacing batteries, replace both at the same time. Do not mix types or brands or use old and new batteries together. This could damage the device.

## Using the Presenter

1. Remove the USB receiver from the bottom front of the Presenter by inserting your fingernail into the lip and nudging it out.
2. Plug the USB receiver into a powered USB port on your computer. Your computer may indicate that new hardware has been installed.
3. On your computer, open a presentation using your chosen presentation software.

*Refer to the Overview on pages 2-3 for information on the functions of the individual buttons.*

## Troubleshooting

Problem	Solution
My computer is not responding to the Presenter.	<ul style="list-style-type: none"><li>• Make sure the batteries have power and are installed in the correct orientation.</li><li>• Make sure the receiver is plugged into your computer's USB port.</li><li>• Remove and reseat the receiver in your computer's USB port.</li></ul>
The laser pointer is not working when the USB receiver is inside the Presenter.	<ul style="list-style-type: none"><li>• The laser pointer is designed to operate only when the USB receiver is removed from its slot in the Presenter. Remove the USB receiver from the Presenter to use the laser pointer.</li></ul>

## Precautions

- Please read and follow the instructions in this manual for proper use of this device.
- Keep this product away from water and flammable gases or liquids.
- Use a soft, slightly moistened cloth when cleaning. Do not use solvents or abrasive substances.
- This product has no serviceable parts.
- Do not open this device for maintenance.



This product emits a Class II laser. Do not stare into the beam. The laser beam can cause permanent damage to eyes. Keep this device away from children.

## Federal Communications Commission

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

### Note

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.



This device and its antenna(s) must not be co-located or operating in conjunction with any other antenna or transmitter.

## EU Declaration of Conformity

This product is carrying the CE-Mark in accordance with the related European Directives.

## Specifications

---

- Frequency: 2.47 GHz
- Remote range: 50' (15.2 m)
- Power source: Two (2) AAA batteries
- Output power: <1 mW
- System requirements
  - Available USB port on the computer
  - Windows 98/ME/2000/XP/Vista/7/8 or above; Mac OS X version 10.4 or above.
- Dimensions: 5.2" × 1.3" × 1.1" (13.2 × 3.2 × 2.8 cm)
- Weight (with batteries): 2.1 oz. (60 g)

# One-Year Limited Warranty

This XCELLON product is warranted to the original purchaser to be free from defects in materials and workmanship under normal consumer use for a period of one (1) year from the original purchase date or thirty (30) days after replacement, whichever occurs later. The warranty provider's responsibility with respect to this limited warranty shall be limited solely to repair or replacement, at the provider's discretion, of any product that fails during normal use of this product in its intended manner and in its intended environment. Inoperability of the product or part(s) shall be determined by the warranty provider. If the product has been discontinued, the warranty provider reserves the right to replace it with a model of equivalent quality and function.

This warranty does not cover damage or defect caused by misuse, neglect, accident, alteration, abuse, improper installation or maintenance. EXCEPT AS PROVIDED HEREIN, THE WARRANTY PROVIDER MAKES NEITHER ANY EXPRESS WARRANTIES NOR ANY IMPLIED WARRANTIES, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. This warranty provides you with specific legal rights, and you may also have additional rights that vary from state to state.

To obtain warranty coverage, contact the Xcellon Customer Service Department to obtain a return merchandise authorization ("RMA") number, and return the defective product to Xcellon along with the RMA number and proof of purchase. Shipment of the defective product is at the purchaser's own risk and expense.

For more information or to arrange service, visit [www.xcellongear.com](http://www.xcellongear.com) or call Customer Service at 212-594-2353.



Product warranty provided by the Gradus Group.

[www.gradusgroup.com](http://www.gradusgroup.com)

Xcellon is a registered trademark of the Gradus Group.

© 2014 Gradus Group LLC. All Rights Reserved.