

Mini-Converter

LUT-box

Installation & Operation Guide

Version 1.0

Published: May 15, 2014



Because it matters.™

AJA[®]
VIDEO SYSTEMS

Table of Contents

Notices	4
Trademarks	4
Copyright	4
Contacting Support	4
Chapter 1: Introduction	5
Overview	5
Features	5
Block Diagram	6
About LUT Data Read and Write	6
I/O Connections	7
Installation	7
Chapter 2: Operation	8
DIP Switch Settings	8
USB Control and Setup—Using AJA MiniConfig	9
Installing MiniConfig on a Mac	9
Installing MiniConfig on a PC	9
Running MiniConfig	9
PC Startup	9
Mac Startup	10
Saving Setups	10
Operating MiniConfig	10
Tabbed Screens	12
Input Tab Screen	12
Input Video Selections	12
HDMI Output Tab Screen	13
HDMI Output Video Selections	13
SDI Output Tab Screen	14
SDI Output Video Selections	14
Audio Tab Screen	15
Audio Selections	15
LUT Tab Screen	16
LUT Selections	16
Update Tab Screen	18
Software Update Procedure	18
Info Tab Screen	19
Appendix A: Specifications	20
Video Input	20
Input Formats	20
Video Output	20
Audio Input	21
Audio Output	21
LUT File Format Support	21
Power	21
Size	21
Appendix B: Safety and Compliance	22
Federal Communications Commission (FCC) Compliance Notices	22
Class B Interference Statement	22

FCC Caution	22
Canadian ICES Statement	22
European Union and European Free Trade Association (EFTA) Regulatory Compliance	23
Declaration of Conformity	23
Korea KCC Compliance Statement	24
Taiwan Compliance Statement	24
Japanese Compliance Statement	24
Recycling Notice	24
Translated Warning and Caution Messages	25
Before Operation Please Read These Instructions	25
Warranty Information	31
Limited Warranty	31
Index	32

Notices

Trademarks

AJA®, KONA®, Ki Pro®, KUMO® and XENA® are registered trademarks of AJA Video, Inc., TruZoom™, TruScale™, Ki Pro Mini™, Io Express™, Io HD™, Io™ and “Work. Flow.” are trademarks of AJA Video, Inc.

AirPort, Apple, the Apple logo, AppleShare, AppleTalk, FireWire, iPod, iPod Touch, Mac, and Macintosh are registered trademarks of Apple Computer, Inc. Final Cut Pro, QuickTime and the QuickTime Logo are trademarks of Apple Computer, Inc.

Avid, Avid Media Composer and Avid DNxHD are trademarks of Avid Technology, Inc.

HDMI, the HDMI logo and High-Definition Multimedia Interface are trademarks or registered trademarks of HDMI Licensing LLC.

DVI is a registered trademark of DDWG.

All other trademarks are the property of their respective holders.

Copyright

Copyright © 2014 AJA Video, Inc. All rights reserved. All information in this manual is subject to change without notice. No part of the document may be reproduced or transmitted in any form, or by any means, electronic or mechanical, including photocopying or recording, without the express written permission of AJA Inc.

Contacting Support

When calling for support, have all information at hand prior to calling.

To contact AJA Video for sales or support, use any of the following methods:

Telephone: +1.530.271.3190

FAX: +1.530.271.3140

Web: <http://www.aja.com>

Support Email: support@aja.com

Sales Email: sales@aja.com

Chapter 1: Introduction



Overview

Working with material outside the normal REC709 video color space (such as LOG material) can cause confusion both on set and in the edit suite with colors that are not properly represented for client review and approval. LUT-box ensures that every monitor is showing the correct color “look” for any source signal while still allowing the footage to maintain its original color look and take advantage of additional dynamic range.

Load up to two custom 3D LUTs into LUT-box to adjust the “look” for any source signal with simultaneous outputs to HDMI and SDI monitors from a single LUT-box. Auto controls are available to configure the unit automatically to match the input and output video parameters. Switch between the two LUTs, using MiniConfig or DIP switches, to quickly A/B compare the two.

Once configured, the settings are non-volatile. The unit can be disconnected from USB, powered down, moved to a new location, and placed into operation there, retaining that configuration.

Features

3D LUTs LUT-box supports 3D LUTs at 17x17x17 with 12-bit processing for accurate color representation.

Multiple LUT formats are supported including:


- .3dl
- .lut
- .txt
- .cube

Connectivity LUT-box accepts 3G and Dual-Link input in a wide range of signal formats. Simultaneous SDI and HDMI outputs allow multiple monitors to view the corrected color signal, and in-line monitoring of an SDI feed.

- Audio Integration** Up to 8-channels of embedded SDI and HDMI audio output are supported. You can select which SDI embedded audio input channels are used (Ch 1-8 or Ch 9-16), and can choose to route all eight or just one pair of these channels to the HDMI output. Two channels of analog audio output allow direct external monitoring without the need to disembed the audio separately.
- USB and MiniConfig Support** AJA's free MiniConfig software can be used with any USB-enabled AJA Mini-Converter and provides an easy-to-use graphical interface with detailed information about the current input and output formats. Control all the parameters of any supported AJA Mini-Converter as well as loading firmware updates from AJA that add new features and functionality.
- DIP Switch Control** DIP switches on the bottom of the unit allow local control of some features without a computer. One of the DIP switches is a "Local/Remote" switch. When in the "Local" mode, the remaining DIP switches support a subset of the user controls. When in the "Remote" mode, the normal Mini-Converter non-volatile registers control the unit (as last set).
- Universal Power Supply** All AJA Mini-Converters ship with a Universal Power Supply that includes international plug connections for use around the world.
- 5-year Warranty** All AJA Mini-Converters are covered by a 5-year warranty and AJA's advanced replacement policy. If a replacement is necessary, AJA will ship a new unit immediately without the need to send the original unit back first, ensuring you are up and running again as quickly as possible.

Block Diagram

Figure 1. LUT-box Converter, Simplified Block Diagram




About LUT Data Read and Write

The LUT-box has two areas that can store LUT data, slot 1 and slot 2. Externally accessed (via USB) LUT file data is written directly into a LUT-box slot, where it acquires a proprietary internal data structure. Data residing in one of the LUT-box slots can be read from that slot, and then be sent to an external location via USB. When sending the data, you can select a LUT file format (.3dl, .lut, .cube) for the data, and produce a file at that destination location that can be used with other LUT-boxes and color management applications. This also makes it possible to convert LUT files from one format to another.

The file name of the source of the LUT data just written into a LUT-box slot is displayed on the MiniConfig LUT screen. The entire path to that file can be displayed by hovering the cursor over the LUT slot field. Similarly, the file name and path to where LUT data that was just read from a slot was sent can be identified in the same way. However, this file and path information is temporary. Subsequent actions will change it. The LUT file names and paths associated with the current LUT-box slot data are not permanently retained.

I/O Connections

Figure 2. LUT-box Converter



NOTE: The Lock LED indicates valid input video by color. Red is HD video, amber is 3G video, off is no input.

Installation

Typically, LUT-box installation consists of the following steps:

1. Ensure the LUT-box is disconnected from power.
2. Connect equipment to the SDI input connector(s), and to the SDI out and/or HDMI out connectors.
3. Connect audio equipment to RCA output connectors (optional)
4. Apply power to the converter (AJA power supply included).
5. The converter will now run using the default factory settings. This default configuration applies no conversion, passing the incoming video to the outputs, and routes the first two channels of embedded audio (if present) to the RCA jacks.
6. To use the LUT box you need to load one or two custom LUTs, using MiniConfig:
 - Install the AJA MiniConfig software (supplied on CD) on your computer.
 - Attach the converter via USB.
 - Make your changes using MiniConfig setup screens.This process is detailed in *"USB Control and Setup—Using AJA MiniConfig"* on page 9.
7. When configured with the correct LUT, the LUT-box can be powered down, moved to the target display, and when powered back up retains those configuration settings.

Chapter 2: Operation

DIP Switch Settings

Eight DIP switches are located on the bottom of the unit. The label identifies the functions of the switch positions. The default shipping position for these switches is Off (left). By default, DIP switch configuration is enabled, and MiniConfig control is disabled.

Figure 3. DIP Switches.




Table 1. DIP Switch Setting Descriptions

SWITCH	FUNCTION	OFF (Left)	ON (Right)
1	Control	Selects Local (DIP), and blocks MiniConfig control.	Selects Remote (MiniConfig), and disables DIP switches 2-8.
2	SDI Input Mode	SDI 1	SDI 1+2 (Dual Link)
3	HDMI mode	HDMI	DVI
4	AUX 1 (SDI Pass Through)	Apply LUT processing, if enabled, and any PsF to P conversion on the SDI output.	Bypass LUT processing, if enabled, and any PsF to P conversion on the SDI output.
5-6	AUX 2 - 3	Reserved	Reserved
7	LUT Slot Select	Slot 1	Slot 2
8	LUT Enable	Bypass - No LUT processing is applied	Enable - The selected LUT processing is applied.

USB Control and Setup—Using AJA MiniConfig

Installing MiniConfig on a Mac

To install the application on a Mac, insert the CD supplied with the Mini-Converter into the computer, drag the “AJA MiniConfig” application for your platform (Mac or PC) to your desktop or an applications folder.



AJA MiniConfig

NOTE: Macintosh computers must be Intel-based (G5, G4 and earlier models will not work with MiniConfig).

Installing MiniConfig on a PC

To install the application on a Windows PC, insert the CD supplied with the Mini-Converter into the computer, locate the “MinInstaller” application, and then double-click it.

Figure 4. MiniConfig Setup Wizard on PC



A Setup Wizard will guide you through the installation. Just click Next to begin.

Answer all questions in the subsequent dialogues; when done, you will be able to locate the MiniConfig application in the AJA folder in the Programs listing.


Running MiniConfig

Connect the Mini-Converter to the PC or Mac via the supplied USB cable. Connect the external power supply (supplied) to the Mini-Converter.

PC Startup


To run MiniConfig on a PC, find the AJA MiniConfig in the program list and locate the AJA MiniConfig application.

Figure 5. PC MiniConfig Startup



Mac Startup To run MiniConfig on a Mac, double-click the Applications folder and locate the AJA MiniConfig application. Double-click the application to launch it.

Figure 6. Mac MiniConfig Startup



NOTE: On a Mac, when the Mini-Converter is connected to the USB port, you may see an alert like that shown below. If you do, press Cancel—this alert can be ignored.

Figure 7. Mac Network Message (ignore)



Saving Setups A *File* menu at the top of the MiniConfig application menu bar allows you to *Save* the state of the Mini-Converter, with your current settings, to a file for later recall. This allows you to set up the converter for different applications, storing each (with *Save*) to a unique name for easy recall—using the *Open* menu item. A *Revert to Factory Settings* menu item similarly allows you to change the settings back to AJA's factory defaults. An *Edit* menu allows you to cut and paste values to/from fields, just as in other applications.

Operating MiniConfig

The MiniConfig application provides a graphic interface for viewing settings and updating software. It consists of an information area at the top that shows the available Mini-Converters attached to the computer via USB, with a graphical rendering of the selected Mini-Converter showing all the connectors and their current state.

Colored text next to the connectors indicates the signal type and what the Mini-Converter is doing:

- *Blue* text indicates the values automatically selected
- *Black* text indicates values that you have manually selected
- *Red* text indicates the Mini-Converter is not detecting a signal or cannot negotiate with the attached device

NOTE: Even if no output device is detected, it still shows the signal it is outputting.


NOTE: Configuration settings in red will change based on the attached output device as well as input signals. For improved accuracy and reliability, you should configure the Mini-Converter only when the target output device is attached and input signals are supplied at the inputs.

Screens are virtually the same on both PC and Mac, with subtle differences that reflect the general look of the platform environment.

Running Multiple Mini-Converters:

MiniConfig can manage multiple AJA Mini-Converters connected via USB—even when they are of differing types. However it only connects to one at a time. You can choose which Mini-Converter you wish to control using the pulldown menu in the upper right hand corner. If you want to configure and update multiple Mini-Converters in parallel, you can do it by running multiple instances of the MiniConfig application and have each control a different Mini-Converter.

Figure 8. MiniConfig, Video Screen



NOTE: The Lock LED indicates valid input video by color. Red is HD video, amber is 3G video, off is no input.

Selecting a Mini-Converter with the dropdown menu causes this application to connect to the selected converter. The graphic of Mini-Converter and text below it provides:

- Type of converter
- Firmware version
- Serial number of the unit


A status field at the bottom of the screen shows if your application is connected and communicating with the Mini-Converter.

When configuring the Mini-Converter, select it from the top pulldown, view the current settings and change any values. Any changes you make are immediately implemented, overwriting previous settings and are saved to the Mini-Converter's non-volatile memory.

Tabbed Screens The Tabs delineate control screens with groups of controls for each type of task to be performed. The controls for the actual configuration parameters are specific to each Mini-Converter type. Click on any of the tab buttons and the screen below will change to match. Each of these screens are described on the following pages.

Input Tab Screen

Figure 9. MiniConfig, Input Tab Screen



Input Video Selections Use the Input screen to view and make changes to the converter's input settings.

Video Source: Selects the input video connectors to use. Choose from the following:

- SDI 1 (Single Link (SL) video, using only the SDI 1 input BNC) (default)
- SDI 1 +2 (Dual Link (DL) video, using both BNCs 1 and 2)

Color Space: Selects the Input Video Color Space. Choose from the following:

- Auto - automatically selects color mode based on the input video parameters and payload ID (default).
- 422 YCbCr (SL)
- 444 RGB (DL)
- 444 YCbCr (DL).


RGB Range: Selects the Input Video Color Range. Choose SMPTE (default) or Full color range. Only applicable if SDI input is 444 RGB format.

Bit Depth: Selects the input video bit depth. Choose from Auto, 8-bit, 10-bit, or 12 bit. Choosing “Auto” automatically selects the bit depth based on the input video parameters and the payload ID.

Video Format: Selects the Input Video Format. Choose from Auto, Progressive, Interlaced, or PsF. Choosing “Auto” automatically selects the format based on the input video parameters and the payload ID.

HDMI Output Tab Screen

Figure 10. MiniConfig, HDMI Output Tab Screen



HDMI Output Video Selections

Use the HDMI Output screen to view and make changes to the converter’s HDMI video output settings.

RGB Range: Selects the Input Video Color Range. Choose SMPTE or Full color range.


Bit Depth: Selects the input video bit depth. Choose from Auto, 8-bit, 10-bit, or 12 bit. Choosing “Auto” automatically selects the bit depth based on the input video parameters and the payload ID.

2K Crop: Select from Off or On. Provides the option of center cutting 2Kx1080 video signals to make 1920x1080. Default is Off.

HDMI/DVI: Choose Auto, HDMI, or DVI. When DVI is selected, any audio signals present are not passed. DVI only supports 8-bit video. Choosing “Auto” (default) automatically selects the output mode based on the attached device’s capabilities.

SDI Output Tab Screen

Figure 11. MiniConfig, SDI Output Tab Screen



SDI Output Video Selections

Use the SDI Output screen to view and make changes to the converter's SDI video output settings.

RGB Range: Selects the Input Video Color Range. Choose SMPTE (default) or Full color range. Only applicable if SDI output is 444 RGB format.

PsF Mode: Selects what mode an incoming PsF signal will have on the SDI output. Choose Psf (default) or Progressive. Only applicable if SDI input is PsF video, and the SDI output *Pass Through* setting is Off.

NOTE: *The LUT-Box HDMI output is always progressive for PsF input video.*


Pass Through: Choose Off or On (default is Off). When On, LUT processing is bypassed on the SDI output. This permits the comparison of unprocessed pass through SDI video on the SDI output alongside LUT processed video displayed on the HDMI output.

3G Level B: Choose from Auto (default), Level A, or Level B. Auto selects the input 3G format.

NOTE: *The SDI output color space and bit depth always follows the SDI input.*

Audio Tab Screen

Figure 12. MiniConfig, Audio Tab Screen



Audio Selections Use the Audio screen to view and make changes to the LUT-box settings.

NOTE: When using the DVI video protocol no audio is output on the HDMI connector, since that protocol is video only.

Input Source: Choose which group of eight embedded SDI input audio channels on the SDI1 input connector to use for routing to the audio outputs.

- SDI1 Ch. 1-8
- SDI1 Ch. 9-16

Output Channel Count: Choose Auto, 2-channel or 8-channel embedded audio for the HDMI output. Choosing "Auto" automatically selects the audio channels based on the attached device's capabilities. This control does not affect the SDI output, which always embeds 8 audio channels.


Analog Audio Select: Choose which two incoming SDI audio channels from the selected group are routed to the analog audio outputs. Choose from Ch 1-2 (9-10) through Ch 7-8 (15-16).

Audio Offset In Frames: Permits time shifting the audio outputs in relationship to the video (for example, to correct for lip sync problems), in 1/16 of a frame increments. Delay range is up to +7.0 video frames. The actual time duration of delay will vary depending on the frame rate of the format being converted.

NOTE: Any video to audio delay caused by LUT processing is automatically corrected. Zero offset sets the output video to audio relationship the same as the incoming signals.

LUT Tab Screen

Figure 13. MiniConfig, LUT Tab Screen




LUT Selections Use the LUT screen to view and make changes to the LUT-box LUT settings. With this screen you can write and read LUT data, enable and disable LUT processing, and switch between two LUTs.

Enable 3D LUT: Enables LUT processing. Choose from On or Off. Default is On. Clicking on the control toggles between the two states, allowing you to watch the output on a display device as you apply and remove LUT processing.

Apply Slot: When 3D LUT processing is enabled above, this setting chooses a LUT slot. The LUT data currently residing in that slot will be used. Choose from Slot 1 or Slot 2. Default is Slot 1. Clicking on either control toggles between Slot 1 and Slot 2, allowing you to watch the output on a display device as you switch between the two LUTs.

3D LUT 1: Clicking on the box to the right opens a browser, allowing you to navigate to any location the computer can access.

Figure 14. Browsers for LUT Write



To write LUT data into Slot 1, do the following:

1. Navigate to a browser location that has the desired LUT file.
2. Select the LUT file and click Open. That sets the path to that file and closes the browser.
3. Click the *Write Slot 1* button on the right. The data will be written to Slot 1.

The file name remains displayed in this box until another action is performed. Hovering the cursor over the box shows the full path to that file.


NOTE: *The last selected path and file name is displayed, which may not represent the actual LUT data currently residing in that slot.*

3D LUT 2: Same as 3DLUT 1 above, but affects Slot 2.

Write Slot 1: After navigating to and selecting a LUT file in the box on the left, click this button to write that LUT data into Slot 1. The Progress thermometer bar is activated, "Parsing" and "Uploading" status messages are displayed, and when finished a "Write Succeeded!" message appears.

Read Slot 1: Clicking on the Read Slot 1 button opens a browser that defaults to the last location, from which you can navigate to a new location.

Figure 15. Browsers for LUT Read



To read the LUT data from Slot 1, create a LUT file, and save that LUT file to that browser location, do the following:

1. Enter a file name in the *Save As:* or *File name:* box.
2. Select a LUT file format in the *Files of Type:* or *Save as type:* box.
3. Click the *Save* button. The Progress thermometer bar is activated, and when finished a "Read Succeeded!" message appears.

The file name remains displayed in this box until another action is performed. Hovering the cursor over the box shows the full path to that file.

NOTE: *The last selected path and file name is displayed, which may not represent the actual LUT data currently residing in that slot.*


Write Slot 2: Same as Write Slot 1 above, but affects Slot 2.

Read Slot 2: Same as Read Slot 1 above, but affects Slot 2.

Write Both Slots: After setting the path to two LUT files in the 3D LUT 1 and 3D LUT 2 browser windows, clicking on this button saves the data to both Slot 1 and Slot 2 simultaneously.

Update Tab Screen

Figure 16. MiniConfig, Update Tab Screen



Indicators and Controls Use this Update screen to view the software version or install new software.

NOTE: When discussing Mini-Converters, “Firmware” is software that will be stored in the Mini-Converter’s non-volatile memory and used when it is powered up. This is separate from the MiniConfig application software. The version numbers shown in the Update screen refer only to the firmware.

Installed: This field shows the version of the firmware currently installed inside the Mini-Converter.

Desired: This field shows the version of firmware embedded in the MiniConfig application which you can install into the Mini-Converter by clicking the *Update* button.

Update: This button initiates a software update operation loading the “Desired” version of firmware into the Mini-Converter’s non-volatile memory.

Progress: This indicator bar shows the progress of software being installed.

Software Update Procedure

1. Check the AJA website for new MiniConfig software for your Mini-Converter. If new software is found, download it and uncompress the file archive (zip). Here is the URL to use when checking:

<http://www.aja.com/en/products/mini-converters/mini-config-software>


2. Connect the Mini-Converter to a Mac or PC via a USB port on the computer and run the new MiniConfig software just downloaded.
3. Click on the Update tab screen.
4. Check the Installed version level against the Desired version level. If the Desired is newer, then click the *Update* button to download the new firmware to the Mini-Converter.

Progress will be shown via the Progress thermometer bar, and when completed an “Update Succeeded” message appears.

Info Tab Screen

This screen provides basic information about the Mini-Converter.

Figure 17. MiniConfig, Info Screen



Name: This field allows you to give your Mini-Converter a name. This may be useful if you have several Mini-Converters attached to a Mac/PC via USB so you can distinguish one of them easily (especially if they're the same model).

Type: This is the factory set model name of the Mini-Converter.

Assembly: This is the factory assembly number.

Serial Number: This is the factory set unique serial number of your unit. If you ever call AJA Support for service, you may be asked for this number.

Appendix A: Specifications

Video Input

HD/3G-SDI with embedded audio (2 x BNCs)

- HD single link
- HD dual link
- 3G single link
- YCbCr 4:2:2 8-bit and 10-bit, RGB 4:4:4 10-bit and 12-bit supported

Input Formats

- 3G-SDI Input**
- 1920x1080p 4:2:2, 50/59.94/60Hz, Level A and Level B
 - 2048x1080p 4:2:2, 50/59.94/60Hz, Level A and Level B
 - 1920x1080p 4:4:4, 23.98/24/25/29.97/30Hz, Level B
 - 1920x1080PsF 4:4:4, 23.98/24/25/29.97/30Hz, Level B
 - 1920x1080i 4:4:4, 50/59.94/60Hz, Level B
 - 2048x1080p 4:4:4, 23.98/24/25/29.97/30Hz, Level B
 - 2048x1080PsF 4:4:4, 23.98/24/25/29.97/30Hz, Level B

- HD-SDI Input**
- 1920x1080p 4:2:2, 23.98/24/25/29.97/30Hz
 - 1920x1080i 4:2:2, 50/59.94/60Hz
 - 1920x1080PsF 4:2:2, 23.98/24/25/29.97/30Hz
 - 2048x1080p 4:2:2, 23.98/24/25/29.97/30Hz
 - 2048x1080PsF 4:2:2, 23.98/24/25/29.97/30Hz
 - 1280x720p 4:2:2, 50/59.94/60Hz

- HD-SDI Dual Link Input**
- 2x1920x1080p 4:4:4, 23.98/24/25/29.97/30Hz
 - 2x1920x1080PsF 4:4:4, 23.98/24/25/29.97/30Hz
 - 2x2048x1080p 4:4:4, 23.98/24/25/29.97/30Hz
 - 2x2048x1080PsF 4:4:4, 23.98/24/25/29.97/30Hz
 - 2x1920x1080p 4:2:2, 50/59.94/60Hz
 - 2x2048x1080p 4:2:2, 50/59.94/60Hz

Video Output

- HD/3G-SDI with embedded audio (1 x BNC)
- HDMI with embedded audio, up to 36-bit Deep Color Support (1xHDMI 1.4 Type A)

NOTE: *PsF inputs are always converted to progressive on the HDMI output. MiniConfig allows the SDI output to be set to either PsF or progressive for a PsF input signal.*

NOTE: *HDMI/DVI output is always RGB color space.*

Audio Input

- Digital**
- SDI embedded audio, up to 8 channels

Audio Output

- Digital**
- SDI embedded audio, up to 8 channels
 - HDMI embedded audio, 2 or 8 channels
- Analog**
- 2-channel RCA-style (-10dBV nominal)

LUT File Format Support

17 point 3D LUTs are supported in these formats:

- .lut
- .txt
- .3dl
- .cube

Power

- Uses AJA Power Supply model DWP-U-R1 (included)
- 100-240V, 50/60Hz Universal Input
- +5V DC regulated, 7.5 watt capacity

Size

- 5.8" x 3.1" x 1" (147mm x 79mm x 25mm)

Appendix B: Safety and Compliance

Federal Communications Commission (FCC) Compliance Notices

Class B Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15, Subpart B of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Canadian ICES Statement

Canadian Department of Communications Radio Interference Regulations

This digital apparatus does not exceed the Class B limits for radio-noise emissions from a digital apparatus as set out in the Radio Interference Regulations of the Canadian Department of Communications. This Class B digital apparatus complies with Canadian ICES-003.

Règlement sur le brouillage radioélectrique du ministère des Communications

Cet appareil numérique respecte les limites de bruits radioélectriques visant les appareils numériques de classe B prescrites dans le Règlement sur le brouillage radioélectrique du ministère des Communications du Canada. Cet appareil numérique de la Classe B est conforme à la norme NMB-003 du Canada.

European Union and European Free Trade Association (EFTA) Regulatory Compliance

This equipment may be operated in the countries that comprise the member countries of the European Union and the European Free Trade Association. These countries, listed in the following paragraph, are referred to as The European Community throughout this document:

AUSTRIA, BELGIUM, BULGARIA, CYPRUS, CZECH REPUBLIC, DENMARK, ESTONIA, FINLAND, FRANCE, GERMANY, GREECE, HUNGARY, IRELAND, ITALY, LATVIA, LITHUANIA, LUXEMBOURG, MALTA, NETHERLANDS, POLAND, PORTUGAL, ROMANIA, SLOVAKIA, SLOVENIA, SPAIN, SWEDEN, UNITED KINGDOM, ICELAND, LICHTENSTEIN, NORWAY, SWITZERLAND

Declaration of Conformity

Marking by this symbol indicates compliance with the Essential Requirements of the EMC Directive of the European Union 2004/108/EC.



This equipment meets the following conformance standards:

Safety: CB: IEC 60065 + Amd 1 + Amd 2

NRTL: UL 60065: 2003 R9.12, CAN/CSA-C22.2 No. 60065-03 + A1:06 (R2012) + A2:12

GS: EN 60065: 2002 + A1 + A11 +A2 + A12

Additional licenses issued for specific countries available on request.

Emissions: EN 55103-1: 2009

EN 61000-3-2 (2009-04), EN 61000-3-3 (2008-06)

Immunity: EN 55103-2: 2009

EN 61000-4-2 (2008-12), EN 61000-4-3 (2010-04), EN 61000-4-4 (2011-03), EN 61000-4-5 (2005-11), EN 61000-4-6 (2008-10), EN 61000-4-8 (2009-09), EN 61000-4-11 (2004-03)

The product is also licensed for additional country specific standards as required for the International Marketplace.



Warning!

This is a Class B product. In a domestic environment, this product may cause radio interference, in which case, the user may be required to take appropriate measures.

Achtung! Dieses ist ein Gerät der Funkstörgrenzwertklasse B. In Wohnbereichen können bei Betrieb dieses Gerätes Rundfunkstörungen auftreten, in welchen Fällen der Benutzer für entsprechende Gegenmaßnahmen verantwortlich ist.

Attention! Ceci est un produit de Classe B. Dans un environnement domestique, ce produit risque de créer des interférences radioélectriques, il appartiendra alors à l'utilisateur de prendre les mesures spécifiques appropriées.

The product is also licensed for additional country specific standards as required for the International Marketplace.

Korea KCC Compliance Statement

<p>B급 기기 (가정용 방송통신기자재)</p>	<p>이 기기는 가정용(B급) 전자파적합기기로서 주로 가정에서 사용하는 것을 목적으로 하며, 모든 지역에서 사용할 수 있습니다.</p>
<p>Class B (Broadcasting Communication Equipment for Home Use)</p>	<p>As an electromagnetic wave equipment for home use (Class B), this equipment is intended to use mainly for home use and may be used in all areas.</p>

Taiwan Compliance Statement

This is a Class B product based on the standard of the Bureau of Standards, Metrology and Inspection (BSMI) CNS 13438, Class B.

Japanese Compliance Statement

2. Class B ITE

この装置は、クラスB情報技術装置です。この装置は、家庭環境で使用することを目的としていますが、この装置がラジオやテレビジョン受信機に近接して使用されると、受信障害を引き起こすことがあります。

取扱説明書に従って正しい取り扱いをして下さい。

VCCI-B

This is a Class B product based on the standard of the VCCI Council. If this is used near a radio or television receiver in a domestic environment, it may cause radio interference. Install and use the equipment according to the instruction manual.

Recycling Notice

	<p>This symbol on the product or its packaging indicates that this product must not be disposed of with your other household waste. Instead, it is your responsibility to dispose of your waste equipment by handing it over to a designated collection point for the recycling of waste electrical and electronic equipment. The separate collection and recycling of your waste equipment at the time of disposal will help conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment. For more information about where you can drop off your waste for recycling, please contact your local authority, or where you purchased your product.</p>
---	---

Translated Warning and Caution Messages

The following caution statements, warning conventions, and warning messages apply to this product and manual.



Warning Symbol



Caution Symbol

Before Operation Please Read These Instructions

	<p>Warning! Read and follow all warning notices and instructions marked on the product or included in the documentation.</p> <p>Avertissement ! Lisez et conformez-vous à tous les avis et instructions d'avertissement indiqués sur le produit ou dans la documentation.</p> <p>Warnung! Lesen und befolgen Sie die Warnhinweise und Anweisungen, die auf dem Produkt angebracht oder in der Dokumentation enthalten sind.</p> <p>¡Advertencia! Lea y siga todas las instrucciones y advertencias marcadas en el producto o incluidas en la documentación.</p> <p>Aviso! Leia e siga todos os avisos e instruções assinalados no produto ou incluídos na documentação.</p> <p>Avviso! Leggere e seguire tutti gli avvisi e le istruzioni presenti sul prodotto o inclusi nella documentazione.</p>
---	---

	<p>Warning! Do not use this device near water and clean only with a dry cloth.</p> <p>Avertissement! N'utilisez pas cet appareil près de l'eau et nettoyez-le seulement avec un tissu sec..</p> <p>Warnung! Das Gerät nicht in der Nähe von Wasser verwenden und nur mit einem trockenen Tuch säubern.</p> <p>¡Advertencia! No utilice este dispositivo cerca del agua y límpielo solamente con un paño seco.</p> <p>Aviso! Não utilize este dispositivo perto da água e limpe-o somente com um pano seco.</p> <p>Avviso! Non utilizzare questo dispositivo vicino all'acqua e pulirlo soltanto con un panno asciutto.</p>
---	--

**Warning!**

Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.

Avertissement ! Ne bloquez aucune ouverture de ventilation. Suivez les instructions du fabricant lors de l'installation.

Warnung! Die Lüftungsöffnungen dürfen nicht blockiert werden. Nur gemäß den Anweisungen des Herstellers installieren.

¡Advertencia! No bloquee ninguna de las aberturas de la ventilación. Instale de acuerdo con las instrucciones del fabricante.

Aviso! Não obstrua nenhuma das aberturas de ventilação. Instale de acordo com as instruções do fabricante.

Avviso! Non ostruire le aperture di ventilazione. Installare in conformità con le istruzioni del fornitore.

**Warning!**

Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.

Avertissement ! N'installez pas l'appareil près d'une source de chaleur telle que des radiateurs, des bouches d'air de chauffage, des fourneaux ou d'autres appareils (amplificateurs compris) qui produisent de la chaleur.

Warnung! Nicht in der Nähe von Wärmequellen wie Heizkörpern, Heizregistern, Öfen oder anderen Wärme erzeugenden Geräten (einschließlich Verstärkern) aufstellen.

¡Advertencia! No instale cerca de fuentes de calor tales como radiadores, registros de calor, estufas u otros aparatos (incluidos amplificadores) que generan calor.

Aviso! Não instale perto de nenhuma fonte de calor tal como radiadores, saídas de calor, fogões ou outros aparelhos (incluindo amplificadores) que produzam calor.

Avviso! Non installare vicino a fonti di calore come termosifoni, diffusori di aria calda, stufe o altri apparecchi (amplificatori compresi) che emettono calore.

**Warning!**

Since the Mains plug is used as the disconnection for the device, it must remain readily accessible and operable.

Avertissement! Puisque la prise principale est utilisée pour débrancher l'appareil, elle doit rester aisément accessible et fonctionnelle.

Warnung! Da der Netzstecker als Trennvorrichtung dient, muss er stets zugänglich und funktionsfähig sein.

¡Advertencia! Puesto que el enchufe de la red eléctrica se utiliza como dispositivo de desconexión, debe seguir siendo fácilmente accesible y operable.

Aviso! Dado que a ficha principal é utilizada como a desconexão para o dispositivo, esta deve manter-se prontamente acessível e funcional.

Avviso! Poiché il cavo di alimentazione viene usato come dispositivo di sconnessione, deve rimanere prontamente accessibile e operabile.

**Warning!**

Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the device.

Avertissement! Protégez le cordon d'alimentation pour que l'on ne marche pas dessus ou qu'on le pince, en particulier au niveau des prises mâles, des réceptacles de convenance, et à l'endroit où il sort de l'appareil.

Warnung! Vermeiden Sie, dass auf das Netzkabel getreten oder das Kabel geknickt wird, insbesondere an den Steckern, den Steckdosen und am Kabelausgang am Gerät.

¡Advertencia! Proteja el cable de energía para que no se le pise ni apriete, en especial cerca del enchufe, los receptáculos de conveniencia y el punto del que salen del equipo.

Aviso! Proteja o cabo de alimentação de ser pisado ou de ser comprimido particularmente nas fichas, em tomadas de parede de conveniência e no ponto de onde sai do dispositivo.

Avviso! Proteggere il cavo di alimentazione in modo che nessuno ci cammini sopra e che non venga schiacciato soprattutto in corrispondenza delle spine e del punto in cui esce dal dispositivo.

**Warning!**

Unplug this device during lightning storms or when unused for long periods of time.

Avertissement! Débranchez cet appareil pendant les orages avec éclairs ou s'il est inutilisé pendant de longues périodes.

Warnung! Das Gerät ist bei Gewitterstürmen oder wenn es über lange Zeiträume ungenutzt bleibt vom Netz zu trennen.

¡Advertencia! Desenchufe este dispositivo durante tormentas eléctricas o cuando no se lo utilice por largos periodos del tiempo.

Aviso! Desconecte este dispositivo da tomada durante trovoadas ou quando não é utilizado durante longos períodos de tempo.

Avviso! Utilizzare soltanto i collegamenti e gli accessori specificati e/o venduti dal produttore, quali il treppiedi e l'esoscheletro.

**Warning!**

Do not open the chassis. There are no user-serviceable parts inside. Opening the chassis will void the warranty unless performed by an AJA service center or licensed facility.

Avertissement! Ne pas ouvrir le châssis. Aucun élément à l'intérieur du châssis ne peut être réparé par l'utilisateur. La garantie sera annulée si le châssis est ouvert par toute autre personne qu'un technicien d'un centre de service ou d'un établissement agréé AJA.

Warnung! Öffnen Sie das Gehäuse nicht. Keine der Geräteteile können vom Benutzer gewartet werden. Durch das Öffnen des Gehäuses wird die Garantie hinfällig, es sei denn, solche Wartungsarbeiten werden in einem AJA-Service-Center oder einem lizenzierten Betrieb vorgenommen.

¡Advertencia! No abra el chasis. El interior no contiene piezas reparables por el usuario. El abrir el chasis anulará la garantía a menos que se lo haga en un centro de servicio AJA o en un local autorizado.

Advertência! Não abra o chassi. Não há internamente nenhuma peça que permita manutenção pelo usuário. Abrir o chassi anula a garantia, a menos que a abertura seja realizada por uma central de serviços da AJA ou por um local autorizado.

Avvertenza! Non aprire lo chassis. All'interno non ci sono parti riparabili dall'utente. L'apertura dello chassis invaliderà la garanzia se non viene effettuata da un centro ufficiale o autorizzato AJA.

**Warning!**

This device is a Class B product. Operation of this equipment in a residential area is likely to cause harmful interference, in which case users will be required to take whatever measures may be necessary to correct the interference at their own expense.

Attention! Le périphérique est un produit de Classe B. Le fonctionnement de cet équipement dans une zone résidentielle risque de causer des interférences nuisibles, auquel cas l'utilisateur devra y remédier à ses propres frais.

Achtung! Dies ist ein Gerät der Klasse B. Bei Einsatz des Geräts in Wohngebieten kann es Störungen des Radio- und Fernsehempfangs verursachen. In diesem Fall muss der Benutzer alle notwendigen Maßnahmen ergreifen, die möglicherweise nötig sind, um die Störungen auf eigene Rechnung zu beheben.

¡Precaución! Este es un producto clase B. El uso de este equipo en áreas residenciales puede causar interferencias nocivas, en cuyo caso, se requerirá que los usuarios tomen cualquier medida necesaria para corregir la interferencia por cuenta propia.

Cuidado! Este dispositivo é um produto Classe B. Operar este equipamento em uma área residencial provavelmente causará interferência prejudicial; neste caso, espera-se que os usuários tomem as medidas necessárias para corrigir a interferência por sua própria conta.

Attenzione! Questo dispositivo è un prodotto di Classe B. Il funzionamento di questo apparecchio in aree residenziali potrebbe causare interferenze dannose, nel cui caso agli utenti verrà richiesto di adottare tutte le misure necessarie per porre rimedio alle interferenze a proprie spese.

**Warning!**

Disconnect the external AC power supply line cord(s) from the mains power before moving the unit.

Avertissement! Retirez le ou les cordons d'alimentation en CA de la source d'alimentation principale lorsque vous déplacez l'appareil.

Warnung! Trennen Sie die Wechselstrom-Versorgungskabel vom Netzstrom, bevor Sie das Gerät verschieben.

¡Advertencia! Cuando mueva la unidad desenchufe de la red eléctrica el/los cable(s) de la fuente de alimentación CA tipo brick.

Advertência! Remova os cabos CA de alimentação brick da rede elétrica ao mover a unidade.

Avvertenza! Scollegare il cavo dell'alimentatore quando si sposta l'unità.

**Warning!**

Refer all servicing to qualified service personnel. Servicing is required when the device has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the device, the device has been exposed to rain or moisture, does not operate normally, or has been dropped.

Avertissement ! Référez-vous au personnel de service qualifié pour tout entretien. L'entretien est exigé quand l'appareil a été endommagé de quelque manière que ce soit, par exemple lorsque le cordon d'alimentation ou la prise sont endommagés, que du liquide a été versé ou des objets sont tombés dans l'appareil, que l'appareil a été exposé à la pluie ou à l'humidité, ne fonctionne pas normalement ou est tombé.

Warnung! Das Gerät sollte nur von qualifizierten Fachkräften gewartet werden. Eine Wartung ist fällig, wenn das Gerät in irgendeiner Weise beschädigt wurde, wie bei beschädigtem Netzkabel oder Netzstecker, falls Flüssigkeiten oder Objekte in das Gerät gelangen, das Gerät Regen oder Feuchtigkeit ausgesetzt wurde, nicht ordnungsgemäß funktioniert oder fallen gelassen wurde.

¡Advertencia! Consulte al personal calificado por cuestiones de reparación. El servicio de reparación se requiere cuando el dispositivo ha recibido cualquier tipo de daño, por ejemplo cable o espigas dañadas, se ha derramado líquido o se han caído objetos dentro del dispositivo, el dispositivo ha sido expuesto a la lluvia o humedad, o no funciona de modo normal, o se ha caído.

Aviso! Remeta todos os serviços de manutenção para o pessoal de assistência qualificado. A prestação de serviços de manutenção é exigida quando o dispositivo foi danificado mediante qualquer forma, como um cabo de alimentação ou ficha que se encontra danificado/a, quando foi derramado líquido ou caíram objectos sobre o dispositivo, quando o dispositivo foi exposto à chuva ou à humidade, quando não funciona normalmente ou quando foi deixado cair.

Avviso! Fare riferimento al personale qualificato per tutti gli interventi di assistenza. L'assistenza è necessaria quando il dispositivo è stato danneggiato in qualche modo, ad esempio se il cavo di alimentazione o la spina sono danneggiati, è stato rovesciato del liquido è stato rovesciato o qualche oggetto è caduto nel dispositivo, il dispositivo è stato esposto a pioggia o umidità, non funziona correttamente o è caduto.



Warning!

Only use attachments and accessories specified and/or sold by the manufacturer.

Avertissement! Utilisez seulement les attaches et accessoires spécifiés et/ou vendus par le fabricant.

Warnung! Verwenden Sie nur Zusatzgeräte und Zubehör angegeben und / oder verkauft wurde durch den Hersteller.

¡Advertencia! Utilice solamente los accesorios y conexiones especificados y/o vendidos por el fabricante.

Aviso! Utilize apenas equipamentos/acessórios especificados e/ou vendidos pelo fabricante.

Avviso! Utilizzare soltanto i collegamenti e gli accessori specificati e/o venduti dal produttore.

Warranty Information

Limited Warranty

AJA Video warrants that this product will be free from defects in materials and workmanship for a period of five years from the date of purchase. If a product proves to be defective during this warranty period, AJA Video, at its option, will either repair the defective product without charge for parts and labor, or will provide a replacement in exchange for the defective product.

In order to obtain service under this warranty, you the Customer, must notify AJA Video of the defect before the expiration of the warranty period and make suitable arrangements for the performance of service. The Customer shall be responsible for packaging and shipping the defective product to a designated service center nominated by AJA Video, with shipping charges prepaid. AJA Video shall pay for the return of the product to the Customer if the shipment is to a location within the country in which the AJA Video service center is located. Customer shall be responsible for paying all shipping charges, insurance, duties, taxes, and any other charges for products returned to any other locations.

This warranty shall not apply to any defect, failure or damage caused by improper use or improper or inadequate maintenance and care. AJA Video shall not be obligated to furnish service under this warranty a) to repair damage resulting from attempts by personnel other than AJA Video representatives to install, repair or service the product, b) to repair damage resulting from improper use or connection to incompatible equipment, c) to repair any damage or malfunction caused by the use of non-AJA Video parts or supplies, or d) to service a product that has been modified or integrated with other products when the effect of such a modification or integration increases the time or difficulty of servicing the product.

THIS WARRANTY IS GIVEN BY AJA VIDEO IN LIEU OF ANY OTHER WARRANTIES, EXPRESS OR IMPLIED. AJA VIDEO AND ITS VENDORS DISCLAIM ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. AJA VIDEO'S RESPONSIBILITY TO REPAIR OR REPLACE DEFECTIVE PRODUCTS IS THE WHOLE AND EXCLUSIVE REMEDY PROVIDED TO THE CUSTOMER FOR ANY INDIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES IRRESPECTIVE OF WHETHER AJA VIDEO OR THE VENDOR HAS ADVANCE NOTICE OF THE POSSIBILITY OF SUCH DAMAGES.

Index

Numerics

- 2K Crop (HDMI output) setting 13
- 3D LUT 1 setting 16
- 3D LUT 2 setting 17
- 3G Level B (SDI output) setting 14

A

- Analog Audio Select setting 15
- Apply Slot setting 16
- Assembly of Mini-Converter 19
- Audio Offset In Frames setting 15
- Audio Selections 15
- Audio Tab Screen 15

B

- Bit Depth (HDMI output) setting 13
- Bit Depth (input) setting 13
- Block Diagram 6

C

- Color Space (input) setting 12
- Compliance Statements 22

E

- Enable 3D LUT setting 16

F

- Features 5
- Firmware version 11

H

- HDMI Output Tab Screen 13
- HDMI Output Video Selections 13
- HDMI/DVI setting 13

I

- I/O Connections 7
- Info Tab Screen 19
- Input Source setting 15
- Input Tab Screen 12
- Input Video Selections 12
- Installation 7

L

- LUT
 - Read procedure 17
 - Write procedure 17
- LUT file name 6, 17
- LUT path and file name 6, 17
- LUT Read 6
- LUT Selections 16

- LUT Tab Screen 16
- LUT Write 6

M

- MiniConfig
 - Operation 10
 - Screen Description 11
 - Starting 9
- MiniConfig installation
 - Mac 9
 - PC 9
- Mini-Converter naming 19
- Mini-Converters
 - Multiple 11
- Multiple Mini-Converters 11

N

- Name setting 19

O

- Output Channel Count setting 15
- Overview 5

P

- Pass Through (SDI output) setting 14
- PsF Mode (SDI output) setting 14

R

- Read and Write
 - description 6
- Read LUT Data Procedure 17
- Read Slot 1 button 17
- Read Slot 2 button 17
- RGB Range (HDMI output) setting 13
- RGB Range (input) setting 12
- RGB Range (SDI output) setting 14

S

- Safety Statements 22
- SDI Output Tab Screen 14
- SDI Output Video Selections 14
- Serial number 11
- Serial Number of Mini-Converter 19
- Slot 1 & 2 description 6
- Software Update Procedure 18
- Specifications 20

T

- Tabbed Screens 12
- Type of converter 11
- Type of Mini-Converter 19

U

Update Indicators and Controls 18
Update Tab Screen 18

V

Video Format setting 13
Video Source (input) setting 12

W

Warnings
 Safety 22
Write Both Slots button 17
Write LUT Data Procedure 17
Write Slot 1 button 17
Write Slot 2 button 17