



## INTRODUCTION

Thank you for choosing a Vello Lens Adapter. Vello Lens Adapters allow you to mount a camera body to a telescope, spotting scope, microscope, or certain lenses. You must also have an SLR camera adapter that fits your telescope. You'll also need to minimize shutter release vibrations that can cause blurring during the long exposures typical with these optics. Vello makes a wide range of remotes and shutter release cables to control your shutter. Telescopes and microscopes are not built to support heavy SLRs. Make certain your setup is secure. Please follow the instructions below to mount and remove your Vello Lens Adapter.

Automatic diaphragm (AE metering), and other functions dependent on communication between the camera body and lens, will be disrupted by a lens adapter. You must set exposures manually or meter in aperture priority (stop-down) mode. If the lens does not have a manual aperture collar, the aperture will be stopped to its smallest f/stop. Focusing to infinity is retained.

All images are for illustrative purposes only.

## TO MOUNT THE LENS ADAPTER



 You must have an SLR camera adapter.
 Screw the lens adapter onto the SLR adapter.



Line up the alignment dots on the lens adapter and camera. Rotate the assembly until it locks.



**3.** Remove the eyepiece from your telescope, spotting scope, or microscope.



 Mount the camera/adapter assemblies to your optic device. Make certain the setup is stable.



5. If desired, you can re-align the lens to a specific position. To re-align the lens, use a 2 mm flat-head screwdriver to loosen the three screws on the lens mount. Rotate the lens to the desired position, and tighten the three screws.

## TO REMOVE THE LENS ADAPTER



 If you prefer, you can leave the lens adapter attached to your SLR adapter. Release the camera/adapter assemblies from the telescope.



Press the lens release on the camera, rotate the adapter assembly to release and remove.



**3.** Unscrew the SLR camera adapter from the lens adapter. Replace all protective covers.

## **ONE-YEAR LIMITED WARRANTY**

This VELLO product is warranted to the original purchaser to be free from defects in materials and workmanship under normal consumer use for a period of one (1) year from the original purchase date or thirty (30) days after replacement, whichever occurs later. The warranty provider's responsibility with respect to this limited warranty shall be limited solely to repair or replacement, at the provider's discretion, of any product that fails during normal use of this product in its intended manner and in its intended environment. Inoperability of the product or part(s) shall be determined by the warranty provider. If the product has been discontinued, the warranty provider reserves the right to replace it with a model of equivalent quality and function.

This warranty does not cover damage or defect caused by misuse, neglect, accident, alteration, abuse, improper installation or maintenance, EXCEPT AS PROVIDED HEREIN, THE WARRANTY PROVIDER MAKES NEITHER ANY EXPRESS WARRANTIES NOR ANY IMPLIED WARRANTIES, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. This warrant, provider you with specific legal cipits that the part of the transfer of the provider you with specific legal cipits that they from state to a trate.

To obtain warranty coverage, contact the Vello Customer Service Department to obtain a return merchandiss authorization ("RMA") number, and return the defective product to Vello along with the RMA number and proo of purchases. Shipment of the defective product is at the purchaser's own risk and expense.

For more information or to arrange service, visit www.vellogear.com or call Customer Service at 212-594-235.

Product warranty provided by the Gradus Group.

www.gradusgroup.com

VELLO is a registered trademark of the Gradus Group
© 2014 Gradus Group LLC. All Rights Reserved





www.vellogear.com

© Copyright 2014 Gradus Group

Vello and other names of Vello products are trademarks of Gradus Group. Other product and corporate names mentioned herein are trademarks of their respective holders.