

Introduction

Thank you for choosing Sensei™.

The Sensei Screw-On Lens Hood mounts securely to your camera lens to prevent stray light from entering, thus eliminating glare and lens flare. The lens hood also helps to minimize impact damage to the lens.

Instructions

1. Start with the camera facing away from you, and the TOP label on the lens hood facing up.
2. Match up the lens hood with the thread on the inside of the camera lens, and rotate the hood clockwise two full turns.
3. Keeping the TOP label aligned with the top of the lens, rotate the locking collar on the lens hood clockwise until the collar applies pressure to the front of the lens, securing the lens hood in its correct position.



Note:

Improper installation of the lens hood may cause vignetting – verify that the word “TOP” is facing upward on the hood and the longer “petals” are oriented in top and bottom positions.

One-Year Limited Warranty

This SENSEI product is warranted to the original purchaser to be free from defects in materials and workmanship under normal consumer use for a period of one (1) year from the original purchase date or thirty (30) days after replacement, whichever occurs later. The warranty provider’s responsibility with respect to this limited warranty shall be limited solely to repair or replacement, at the provider’s discretion, of any product that fails during normal use of this product in its intended manner and in its intended environment. Inoperability of the product or part(s) shall be determined by the warranty provider. If the product has been discontinued, the warranty provider reserves the right to replace it with a model of equivalent quality and function.

This warranty does not cover damage or defect caused by misuse, neglect, accident, alteration, abuse, improper installation or maintenance. EXCEPT AS PROVIDED HEREIN, THE WARRANTY PROVIDER MAKES NEITHER ANY EXPRESS WARRANTIES NOR ANY IMPLIED WARRANTIES, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. This warranty provides you with specific legal rights, and you may also have additional rights that vary from state to state.

To obtain warranty coverage, contact the Sensei Customer Service Department to obtain a return merchandise authorization (“RMA”) number, and return the defective product to Sensei along with the RMA number and proof of purchase. Shipment of the defective product is at the purchaser’s own risk and expense.

For more information or to arrange service, visit www.madebysensei.com or call Customer Service at 212-594-2353.

Product warranty provided by the Gradus Group.
www.gradusgroup.com

SENSEI is a registered trademark of the Gradus Group.
© 2015 Gradus Group LLC. All Rights Reserved.

